

S-Access ETHERLINK II

REGENERATORS, LTU AND NTU DEVICES

TECHNICAL DESCRIPTION AND OPERATIONS MANUAL

Version 1.1

Document name

_SA_SAUM_ETHERLINK-II_V1-1_070201.Doc

Revision

16. November 2006

© Copyright ©2006 by S-Access GmbH. The content of this publication may not be reproduced in any part or as a whole, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, magnetic, optical, chemical, photocopying, manual, or otherwise, without the prior written permission of S-Access GmbH. Published S-Access GmbH. All rights reserved.

VERSION CONTROL	8
1 SELECTION GUIDE	9
2 INTRODUCTION.....	10
3 TECHNICAL DESCRIPTION.....	11
3.1 Application and general information about S-Access ETHERLINK II devices	11
3.2 Main features of S-Access ETHERLINK II devices.....	13
3.3 Description of S-Access ETHERLINK II devices	14
3.3.1 Mechanic design.....	14
3.3.2 Sub rack.....	15
3.3.2.1 Stand Alone	17
3.3.2.2 IP-67	19
3.3.3 Remote power supply, wetting current supply and wetting current consumption modes	22
3.3.3.1 Electrical safety regulations when using the remote power supply	22
3.3.3.2 Compatibility of wetting current supply and remote power supply modes	23
3.3.3.3 Remote power consumption for NTUs	23
3.3.3.4 Remote power supply, wetting current supply and wetting current consumption modes for LTUs.....	24
3.3.4 Description of S-Access ETHERLINK II interfaces	26
3.3.4.1 xDSL interface	26
3.3.4.1.1 Master/Slave/Auto.....	27
3.3.4.1.2 Multipair modes.....	27
3.3.4.1.3 Reservation	29
3.3.4.1.4 Automatic configuration of a link	34
3.3.4.2 E1 interface (2 Mbit/s G.703/G.704).....	36
3.3.4.2.1 Transparent and ITU-T G.704.....	37
3.3.4.2.2 CRC4 (cyclic redundancy check).....	37
3.3.4.2.3 AIS Generation (alarm indication signal)	37
3.3.4.2.4 AIS Detection	37
3.3.4.2.5 E1 clock modes.....	38
3.3.4.3 Ethernet interface	39
3.3.5 An integrated switch of 64-kbit/s time slots.....	42
3.3.5.1 E1 mode (transmission of only time slots of E1 streams).....	42
3.3.5.2 Mode of simultaneous transmission of time slots of E1 and Ethernet data ...	43
3.3.6 Test loops	44
3.3.6.1 Analog Loopback.....	45
3.3.6.2 Performance monitoring	45
3.3.6.3 G.826 performance monitoring	45
3.4 Alarm indication	47
3.4.1 LEDs	47
3.4.2 Alarm LEDs.....	49
3.5 Management of S-Access ETHERLINK II devices	51

User Manual

3.5.1	Management of S-Access ETHERLINK II devices with the help of the RS232 interface	51
3.5.1.1	Management of S-Access ETHERLINK II Sub Rack devices	51
3.5.1.2	Management of S-Access ETHERLINK II MiniRack and Stand Alone devices	52
3.6	Management of S-Access ETHERLINK II devices with the help of the Ethernet interface	52
3.6.1.1	Management of S-Access ETHERLINK II devices with the help of the Telnet session	52
3.6.1.2	WEB interface.....	54
3.6.1.3	Management of S-Access ETHERLINK II devices with the help of SNMP....	58
3.7	Installation	60
3.7.1	Installation of a shelf	60
3.7.2	Connection of the power and grounding cables	60
3.7.3	Installation of SubRack devices	61
3.7.4	Cabling.....	61
3.7.5	Connection of line cables.....	61
3.7.6	Connection of the terminal.....	61
3.7.7	Switching the equipment on.....	61
3.7.8	Establishing communication	61
3.7.9	Error parameter control and control of line parameters	62
3.7.10	Programming the parameters of E1 interfaces	63
3.7.11	Measuring the parameters of the organized digital line	63
3.7.12	Connecting the line terminal equipment and checking its operation.....	63
3.7.12.1	Connection of Ethernet.....	64
4	PROGRAMMING GUIDE.....	65
4.1	Command structure	65
4.2	ETHERLINK II software	74
4.3	Configuration storage and application	75
4.4	Groups of commands requiring confirmation	77
4.5	Command syntax	77
4.6	Commands.....	78
4.6.1	Main Menu	78
4.6.1.1	View of the main menu	78
4.6.1.2	System invitation	78
4.6.2	Performance management menu	78
4.6.2.1	<H> command	78
4.6.2.2	<TCPIP> command	79
4.6.2.3	<MAC> command.....	80
4.6.2.4	<G826 E1> command	81
4.6.2.5	<RESETG826> command.....	82
4.6.2.6	<G826> command.....	82
4.6.2.7	<NETSTAT> command	83
4.6.2.8	<RESETNETSTAT> command	84
4.6.2.9	<ALLG826 [N=1..4]> command.....	84

User Manual

4.6.2.10	<RESETALLG826 [N=1..4]> command.....	85
4.6.2.11	<CONNECT N:1..13/R> command.....	85
4.6.2.12	<M> command.....	85
4.6.3	Fault and maintenance management menu	86
4.6.3.1	<H> command	86
4.6.3.2	<NM> command	87
4.6.3.3	STATUS> command.....	87
4.6.3.4	<STATUS ETH> command	89
4.6.3.5	<MACTABLE> command	89
4.6.3.6	<ALARM> command	89
4.6.3.7	<LOOP1 ON/OFF [N=1..4]> command	91
4.6.3.8	<LOOP2 N:ADDR ON/OFF> command	91
4.6.3.9	<STARTAL ON/OFF N> command	91
4.6.3.10	<RESTART [N=1..4]> command	92
4.6.3.11	<RESET> command.....	92
4.6.3.12	<ACO [GROUP ON/OFF]> command.....	92
4.6.3.13	<SOFTUPDATE> command	93
4.6.3.14	<SOFTCONFIRM> command	93
4.6.3.15	<SOFTINFO> command	94
4.6.3.16	<APPLY ALL/NET/VLAN/LINE/SNMP> command.....	94
4.6.3.17	<CONFIRM> command.....	94
4.6.3.18	<BACKUP> command.....	94
4.6.3.19	<RESTORE> command	95
4.6.3.20	Viewing differences of configurations <DIFF N/R/S/B N/R/S/B > command .	95
4.6.3.21	<DUMP N/R/S/B > command	95
4.6.3.22	<LOAD> command.....	96
4.6.3.23	<CONNECT N:1..13/R> command.....	96
4.6.4	Configuration Management menu	97
4.6.4.1	<H> command	97
4.6.4.2	<AUTO [ON/OFF]> command	98
4.6.4.3	<CONFIG> command.....	99
4.6.4.4	<CONFIG R/N/S/B> command.....	103
4.6.4.5	<MASTER ON/OFF/AUTO N> command	103
4.6.4.6	<ANNEX A/B/AB [N=1..4]> command.....	104
4.6.4.7	<RESERVE [list]>, <RESERVE [list] [list]> command.....	104
4.6.4.8	<MULTIPAIR [MODE]> command.....	104
4.6.4.9	<G704 ON/OFF [N]> command.....	105
4.6.4.10	<CRC4 ON/OFF [N]> command.....	105
4.6.4.11	<AISGEN ON/OFF [N]>, <AISDET ON/OFF [N]> commands.....	105
4.6.4.12	<PAM 16/32 [N]> command	105
4.6.4.13	<BASERATE K/AUTO [N=1..4]> command	105
4.6.4.14	<DSLTS list/NONE [N=1..4]> command.....	106
4.6.4.15	<WANTS [list] [N=1..4]> command (Ethernet via E1).....	106
4.6.4.16	<PAYLOAD list/NONE [N=1..4]> command	107
4.6.4.17	<SETCLOCK list [N=1..4]> command	107
4.6.4.18	<PASSWORD USER/ADMIN> command	108

User Manual

4.6.4.19	<SERNUM> command	108
4.6.4.20	<ID N> command	108
4.6.4.21	<CONNECT N:1...13/R> command	108
4.6.4.22	<NET> command	108
4.6.4.23	<H> command	108
4.6.4.24	<NETCONFIG [R/N/S/B]> command	109
4.6.4.25	<INTERFACE NAME COMMAND PARAM > command	112
4.6.4.26	<SPECADDR> command.....	113
4.6.4.27	<VID> command.....	113
4.6.4.28	<ETHSD 10/100/AUTO H/F [N=1..4]> command	113
4.6.4.29	<LPPACKING WAN1/WAN2/WAN3/WAN4 SIZE> command	114
4.6.4.30	<SETIP X.X.X.X> command.....	114
4.6.4.31	<NETMASK X.X.X.X> command.....	114
4.6.4.32	<GATEWAY X.X.X.X> command	114
4.6.4.33	<TRAPIP ADD/DEL X.X.X.X> command	114
4.6.4.34	<COMMUNITY> command	114
4.6.4.35	<SNMPSET ON/OFF> command.....	114
4.6.4.36	<NETDEFAULT> command	114
4.6.4.37	<DEFAULT> command	115
4.6.4.38	<DEFAULT EVERYTHING> command.....	115
4.6.4.39	<M> command.....	115
5	SOFTWARE DOWNLOADING.....	116
5.1	Software loading via the RS232 port with the help of the Flash Loader program	116
5.2	Software loading via the COM port (the X-modem protocol)	120
5.3	Software loading via Ethernet (X-modem and Telnet)	124
6	SERVICE INSTRUCTIONS	125
6.1	General requirements	125
6.2	Evaluation of the quality of the digital channel and operation parameters.....	126
6.3	Activation and deactivation of a loopback.....	126
7	APPENDICES.....	127
7.1	Example of configuration of ETHERLINK II devices	127
7.1.1	Configuration of the S-Access ETHERLINK II device at the Central Office premises.....	127
7.1.2	Configuration of the S-Access ETHERLINK II device at the Customer Premises. 128	
7.1.3	Configuration of the S-Access ETHERLINK II regenerator at the Regenerator Point. 128	
7.2	Configuration of the S-Access ETHERLINK II device at the Central Office premises. 130	
7.3	Configuration of the S-Access ETHERLINK II regenerator at the Regenerator Point.131	
7.4	Connectors' description	133
7.4.1	"Ethernet" connector	133
7.4.2	"xDSL" connector.....	134
7.4.3	"xDSL" connector (IP Regenerator)	135

User Manual

7.4.4	“G703” connector (E1 interfaces for Sub Rack devices)	136
7.4.5	“G703” connector (E1 interface for Stand Alone and MiniRack devices)	137
7.4.6	“Monitor” connector (for MiniRack and Stand Alone devices)	138
7.4.7	“-48VDC” connector	138
7.4.8	“Monitor/TLM” connector (for regenerators IP and PL).....	139
7.5	Ordering information	140

VERSION CONTROL

<i>User Manual Version</i>	<i>Date</i>	<i>Software Version</i>	<i>Major changes to previous version</i>
1.0			Initial version
1.1	16.11.2006		xDSL connector for IP regenerator added

Warnings

INCORRECT USE OF THIS DEVICE, USE IN ANY OTHER ENVIRONMENT AND/OR CHASSIS/HOUSING THAN PROVIDED BY S-ACCESS MIGHT LEAD TO HARMFUL CONDITIONS. FAILURE TO FOLLOW THESE PRECAUTIONS MAY RESULT IN DEATH, SEVERE INJURY OR PROPERTY DAMAGE.

S-ACCESS GMBH REFUSES TO TAKE ANY RESPONSIBILITY; FURTHERMORE, NO WARRANTY IS GRANTED IN SUCH CASE!

Please read this manual carefully before operating the system.
Installation of this equipment has to be done by qualified personnel only.

EU Directive 2002/96/EC and EN50419



This equipment is marked with the above recycling symbol. It means that at the end of the life of the equipment you must dispose of it separately at an appropriate collection point and not place it in the normal domestic unsorted waste stream. (European Union only)

1 SELECTION GUIDE

<div>Functionality</div> <div>S-Access Etherlink II</div>	Standalone	Subrack Card	Protected housing	Single Pair	Dual Pair Bonding	Triple Pair Bonding	Quad Pair Bonding	Point-to-Point	Point-to-Multipoint	E1 (120Ohm) Framed/Unframed	Ethernet Bridge IEEE 802.1q	VLAN (IEEE 802.1q)	Ethernet Add/Drop	Converter Eth to 1/2/4 E1	Remote Power Receiver	Remote Power Source	Console Port Management	Telnet Management	Optional SNMP Management
SA-PAM-SAN-E1B/Eth, V50																			
SA-PAM-SA2N-2E1B/Eth, V51																			
SA-PAM-SAN-Eth, V52																			
SA-PAM-SA2N-Eth, V53																			
SA-PAM-SA4N-Eth, V54																			
SA-PAM-SRL-E1B/4Eth-RP, V60																			
SA-PAM-SRL-4Eth-RP, V61																			
SA-PAM-SRL-2E1B/4Eth-RP, V62																			
SA-PAM-SR2L-2E1B/4Eth-RP, V63																			
SA-PAM-SR2L-4Eth-RP, V64																			
SA-PAM-SR2L-4E1B/4Eth-RP, V65																			
SA-PAM-SR4L-4E1B/4Eth-RP, V66																			
SA-PAM-SRL-4E1/ETHER_CONV																			
SA-PAM-RGN-Eth-IP, V56																			
SA-PAM-RG2N-Eth-IP, V58																			
SA-PAM-RGN-Eth-PL, V56																			
SA-PAM-RG2N-Eth-PL, V58																			

2 INTRODUCTION

The present document describes devices of the S-Access ETHERLINK II family. The document contains the technical description of the devices, installation, configuration, and operation instructions. Appendices containing additional information about the system are also an integral part of the present document.

Warning! Before starting operating the equipment, read carefully PART 5 of the present document. The *guarantee will not be granted* to the device malfunctioning or damaged due to failure to comply with the requirements stated in the Section related to “Service Instructions” of the present document.

Warning! An example of fast configuration of the equipment is described in Appendix 6.1 of the present document.

3 TECHNICAL DESCRIPTION

3.1 Application and general information about S-Access ETHERLINK II devices

S-Access ETHERLINK II devices represent xDSL modems (ITU-T G.991.2– G.shdsl and ITU-T G.991.2 – G.shdsl.bis standards, TC-PAM line encoding). They are designed to organize high-speed data communication channels over symmetric digital subscriber lines (DSLs) with the transmission rates from 200 to 5704 Kbit/s (with the step of 64 Kbit/s). The **TC-PAM** (**T**rellis **C**oded **P**ulse **A**mplitude **M**odulation) encoding used in these devices well combines such characteristics as the transmission range, noise immunity and electromagnetic operability. The number of levels (code states) in TC-PAM is increased up to 32 and a special error correction mechanism is used. To increase the distance range by 2 or more times, **regenerators** can be used.

The family of S-Access ETHERLINK-II includes devices with G.703 and Ethernet network interfaces. Thus, the S-Access ETHERLINK-II equipment provides complex services which allow one to transmit simultaneously voice and data as well as to construct TDM networks of different topologies without using expensive interface converter, multiplexers and cross-connect systems.

The devices of this family include network termination units (**NTUs**) and line termination units (**LTUs**), which are installed at the customer (user) premises and the operator (provider) premises, respectively. In addition, the devices of this family include regenerators. To organize the “point-to-point” topology, the following schemes can be used: NTU – NTU, LTU – LTU or NTU –LTU.

The devices can be powered from local DC and AC sources. Regenerators and NTUs can be fed both locally or remotely from LTUs. Figure 1.1 presents an example of organization of data transmission systems with the help of modems of the S-Access ETHERLINK II family. Other variants of the usage of this equipment are also possible.

User Manual




Figure 3.1 An example of organization of a data communication channel using S-Access ETHERLINK II modems

Notations in the figure:

- ATS: a private automatic branch exchange;
- E1: a 2048-kbit/s digital flow structured according to ITU-T Rec. G.704;
- Management PC: a personal computer used to configure the system;
- Vlan Switch: a switch of Ethernet packets supporting the Vlan function (IEEE 802.1q);
- VoIP: devices of IP telephony (VOICE over IP);
- Ethernet Network: local Ethernet network;
- ETHERLINK-II LTU: S-Access ETHERLINK-II line termination unit;
- ETHERLINK-II NTU: S-Access ETHERLINK-II network termination unit;
- RGNo2: S-Access ETHERLINK-II regenerator.

The devices of this family have different mechanic designs: **Sub Rack** – a unit to be inserted into a 19" AccessGain shelf; **MiniRack** – a 1U (44.5 mm) unit to be inserted into a 19" cabinet; **Stand Alone** – a desktop unit; **IP-67** – a unit in a water-proof plastic or silumin housing (class IP-67); **XCVR** – a unit to be inserted into a hermetic steel housing.

The devices have the following possibilities for monitoring and management:

- Local management and control of remote devices and regenerators – VT 100;
- Local management and control of remote devices and regenerators – Telnet session;
- Operation in complex networks under the unified management system – support of SNMP.

User Manual

The use of the Flash memory as the ROM provides an easy upgrade of the software. xDSL modems are powered from a grounded primary DC source (38 ... 78 V) or remotely. Modems are designed to be used in-doors under the following environmental conditions:

- temperature of ambient air – from -5 ... +45°C;
- relative air humidity – from 5% ... 85% at +25°C.

3.2 Main features of S-Access ETHERLINK II devices

S-Access ETHERLINK II modems represent the next generation of modems of the S-Access ETHERLINK family and have the following features:

1. A new type of line encoding – TC-PAM32 (TC-PAM16 is also supported).
2. Duplex data transmission over one symmetrical pair at 5.7 Mbit/s.
3. Simultaneous transmission of the TDM traffic and Ethernet data.
4. The 802.1q protocol.
5. Different ways of system configuration (for example, remote configuration of devices via Telnet).
6. Embedded WEB interface.
7. The SNMP protocol.
8. Possibility of storing several configurations in the device's EEPROM in order to download the previous settings of the system.
9. Two levels of system users: administrator and user, protected with passwords.
10. The use of the modern circuit printed boards, chips and components.
11. Extended reliability of the equipment.

3.3 Description of S-Access ETHERLINK II devices**3.3.1 Mechanic design**

S-Access ETHERLINK II devices have five mechanic designs:

- Sub Rack (LTU) – a unit to be inserted into a 19” AccessGain shelf;
- Stand Alone (NTU) – a unit to be mounted on a horizontal surface;
-

Table 3.1 NTU and LTU devices.

	<i>Sub Rack</i>	<i>Stand Alone</i>
SA-PAM-SRL-E1B/4Eth-RP, V60	√	
SA-PAM-SRL-4Eth-RP, V61	√	
SA-PAM-SRL-2E1B/4Eth-RP, V62	√	
SA-PAM-SR2L-2E1B/4Eth-RP, V63	√	
SA-PAM-SR2L-4Eth-RP, V64	√	
SA-PAM-SR2L-4E1B/4Eth-RP, V65	√	
SA-PAM-SR4L-4E1B/4Eth-RP, V66	√	
SA-PAM-SAN-E1B/Eth, V50		√
SA-PAM-SA2N-2E1B/Eth, V51		√
SA-PAM-SAN-Eth, V52		√
SA-PAM-SA2N-Eth, V53		√
SA-PAM-SA4N-Eth, V54		√

User Manual

Regenerators have the following mechanic designs:

- **IP-67** – a unit in a water-proof plastic or silumin housing (class IP-67);
- **PL** – a unit in a Stand Alone plastic housing (Desktop)

Table 3.2 Regenerators.

	<i>Plastic Housing</i>	<i>IP-67</i>
SA-PAM-RG2N-Eth-PL, V58	√	
SA-PAM-RGN-Eth-PL, V56	√	
SA-PAM-RG2N-Eth-IP, V58		√
SA-PAM-RGN-Eth-IP, V56		√

3.3.2 Sub rack

Sub Rack ETHERLINK II devices represent a printed circuit board with a front panel. The following LEDs and connectors are located on the front panel of the device:

Table 3.3 Connectors and LEDs on the front panel of the SubRack devices.

<i>Element</i>		<i>Description</i>
1		A LED showing the status of the local device
2		A LED showing the status of the remote device
3		A LED showing the status of the first E1 port
4		A LED showing the status of the second E1 port
5		A LED showing the status of the third E1 port
6		A LED showing the status of the fourth E1 port
ND		A button to set “default” network configurations
Ethernet	1	An RJ45 connector for the connection of the first Ethernet line
	2	An RJ45 connector for the connection of the second Ethernet line
	3	An RJ45 connector for the connection of the third Ethernet line
	4	An RJ45 connector for the connection of the fourth Ethernet line
G.703	1 and/or 3	A DB15 connector (male) of port 1 and/or 3 for the connection to the E1 equipment (G.703)
	2 and/or 4	A DB15 connector (male) of port 2 and/or 4 for the connection to the E1 equipment (G.703)
xDSL	1 and/or 3	An RJ45 connector for the connection of the first and/or third xDSL line + two LEDs
	2 and/or 4	An RJ45 connector for the connection of the second and/or fourth xDSL line + two LEDs




Figure 3.2 Front panel of SA-PAM-SRxxL-xxx devices

3.3.2.1 Stand Alone

From the mechanic point of view, the device represents a case made of shockproof polystyrene to withstand harsh environmental conditions, the case containing the basic elements of the device. The power supply unit represents an external power supply in the form of a plug. The front panel contains the following connectors and LEDs:

Table 3.4 Connectors and LEDs of the Stand Alone devices.


<i>Element</i>	<i>Description</i>
DSL 1	A LED showing the status of the first line interface of the device
DSL 2	A LED showing the status of the second line interface of the device
Eth	A LED showing the status of the Ethernet port
G.703 1	A LED showing the status of the first E1 port
G.703 2	A LED showing the status of the second E1 port
Ethernet	An RJ45 connector for the connection of Ethernet + two LEDs
G.703	An RJ45 connector for the connection to the E1 equipment + two LEDs
Monitor	A DB9 connector (female) for the connection to the control terminal
-48VDC	A connector for the connection to a primary DC source
LP/DP	A toggle of the power supply (local/remote)
xDSL	An RJ45 connector for the connection to the xDSL line + two LEDs
	A grounding bolt



Figure 3.3 S-Access ETHERLINK II devices of the Stand Alone design, top view and front view for the following models SA-PAM-SA2N-2E1B/Eth, V51; SA-PAM-SAN-E1B/Eth, V50; SA-PAM-SA2N-Eth, V53; SA-PAM-SA4N-Eth, V54 and SA-PAM-SAN-Eth, V52


User Manual

Figure 3.4. S-Access ETHERLINK II devices of the Stand Alone design, rear view for the following models SA-PAM-SA2N-2E1B/Eth, V51; SA-PAM-SAN-E1B/Eth, V50; SA-PAM-SA2N-Eth, V53; SA-PAM-SA4N-Eth, V54 and SA-PAM-SAN-Eth, V52 (from top to bottom).

3.3.2.2 IP-67

The device represents a silumin or plastic housing containing the basic elements of the device. The housing design corresponds to the IP-67 class (in accordance with IEC-60529). The housing has two or three (for the plastic housing) cable inputs with stub cables for the connection to xDSL lines, as well as two hermetic RJ-45 connectors, an M4 grounding bolt and a LED for the silumin housing.

User Manual

The regenerators in the silumin housing contain the following connectors and LEDs:

Table 3.5 Connectors and LEDs of silumin-housing regenerators.

<i>Element</i>		<i>Description</i>
"STATUS"		A LED
Ethernet		A hermetic RJ45 connector for the connection of Ethernet
Monitor/TLM		A hermetic RJ45 connector for the connection to the control terminal or to the dry loop
M4 bolt		A grounding bolt
xDSL 1	1 and/or 3	A cable of the first and/or third xDSL line
xDSL 2	2 and/or 4	A cable of the second and/or fourth xDSL line

The regenerators in the plastic housing contain the following connectors and LEDs:

Table 3.6 Connectors and LEDs of plastic-housing regenerators.

<i>Element</i>		<i>Description</i>
DSL1		A LED showing the status of the first line
DSL2		A LED showing the status of the second line (for two-channel regenerators)
Eth		A LED showing the status of the Ethernet port
G703 (above)		A LED showing the status of the first E1 port
G703 (below)		A LED showing the status of the second E1 port
A		A hermetic RJ45 connector for the connection to the control terminal or to the dry loop
B		A hermetic RJ45 connector for the connection of Ethernet
Powering Grounding		Output of the power cable (for locally powered devices) and Grounding cable
xDSL 1	1 and/or 3	A cable of the first and/or third xDSL line
xDSL 2	2 and/or 4	A cable of the second and/or fourth xDSL line


User Manual

Figure 3.5 View of SA-PAM-xxx-IP devices

User Manual

The center-to-center spacing of
fixing holes is
265x160mm
Or
235x190mm
The hole diameter is 6.5 mm





Figure 3.6 View of SA-PAM-xxx- PL devices

3.3.3 Remote power supply, wetting current supply and wetting current consumption modes

The wetting current supply and remote power supply modes can be changed by using jumpers and the management PC.

3.3.3.1 Electrical safety regulations when using the remote power supply

Despite the safe voltage on each wire with respect to the ground (<120 Volts), the use the remote power supply requires one to observe strictly the following rules:

User Manual

- When working with lines and a junction box, the xDSL cable should be disconnected from the device supplying the remote power;
- The insulation of cable pairs, junctions (junction boxes, plinths, etc.) should correspond to norms and standards of the network;
- S-Access ETHERLINK II devices should be grounded.

3.3.3.2 Compatibility of wetting current supply and remote power supply modes

The table of compatibility of the wetting current supply and remote power supply modes is presented below.

The devices operating in pairs should be configured for mutual operation (“√” – compatible). The use of the mode «-» is not recommended because it may cause: high power consumption, degradation of communication (communication stability), the use of additional safety measures. The mode “incompatible” (inc) will not allow the devices to establish communication (because in this case one or both devices will be de-energized).

Wetting current supply and remote power supply modes		NTU or regenerator		LTU			
		Remote power consumption	No	Remote power supply	Wetting current supply	Wetting current consumption	No
NTU or regenerator	Power DP	inc	inc	√	inc	inc	inc
	No	inc	√	-	-	√	√
LTU	Remote power supply	√	-	X	X	X	-
	Wetting current supply	inc	-	X	X	√	-
	Remote power consumption	inc	√	X	√	√	√
	No	inc	√	-	-	√	√

Warning! To prevent the FAILURE OF THE EQUIPMENT, the use of “X” modes IS STRICTLY PROHIBITED!

Table 3.7 Compatible operations of remote power supply and wetting current supply modes.

3.3.3.3 Remote power consumption for NTUs

NTU devices and regenerators can be configured to the local power supply and remote power supply modes (**LP/DP**). The **LP/DP** modes are switched from one to another with the help of a toggle on the rear panel of the device (see Figure 3.7).




Figure 3.7. Position of the switch of LP/DP modes on the NTU board.

Regenerators having the XCVR mechanic design are always powered remotely.
The default settings are:

- for NTUs of the Stand Alone type, the switch is in the **LP** position (local powering);
- for NTUs in the IP and PL housings, the switch is in the **DP** position (remote powering);

3.3.3.4 Remote power supply, wetting current supply and wetting current consumption modes for LTUs

Each channel of LTUs can be configured to supply wetting current, to consume wetting current and to supply remote power:

Switching between the modes is performed by the corresponding jumpers separately for each xDSL channel of the modem (**J11, J12, J13, J14**) (see Figure 3.9).

Jumpers (**XM23, XM26, XM27, XM24, XM25, XM28**) switch the remote power supply mode: **115 Volts or 230 Volts** (see Figure 3.10).


The removed jumpers (**XM18, XM19**) switch between **230-Volt and 200-Volt remote power supply modes** (by default these jumpers are installed).

In the mode of **115 Volts** the device can provide remote powering of **one NTU or single-channel regenerator via any of DSL channels**. Remote power can be supplied to all liner interfaces.

In the mode of **200 Volts** the device can provide remote powering of **one NTU and two single-channel regenerators or three single-channel regenerators**. Remote power can be supplied to line interfaces 1 and 3.

User Manual

In the mode of **230 Volts** the device can provide remote powering of **one NTU and three single-channel regenerators** or **four single-channel regenerators**. Remote power can be supplied to line interfaces 1 and 3.




User Manual

Figure 3.10 Position of jumpers XM23, XM27, XM26, XM24, XM25, XM28 for different voltage modes of the remote power supply.

The default settings are:

- for NTUs of the Stand Alone type, the switch is in the **LP** position (local powering);
- for NTUs in the IP and PL housings, the switch is in the **DP** position (remote powering);
- for LTUs, the remote power voltage is **115 Volts**.

The remote power supply mode in S-Access ETHERLINK II devices has a number of special features:

- Safe voltage in the wire with respect to the ground (<120 Volts);
- Tolerance to micro breaks;
- Automatic restart of the system if failures occur in the remote power supply circuit;
- Protection complying the ITU-T K.20/K.21 Recs;
- Limitation of the remote power supply current (60 mA) with the help of a microcontroller.

3.3.4 Description of S-Access ETHERLINK II interfaces

3.3.4.1 xDSL interface

The operation modes described below refer to the line interface of the device.

The S-Access ETHERLINK-II devices can have 1, 2 or 4 xDSL interfaces. The interfaces can operate independently of each other as well as can be combined to operate in the multipair mode.

All independent xDSL interfaces and groups of xDSL interfaces operating in the multipair mode can be configured separately from the other xDSL interfaces. The multipair mode, the reservation mode and the mode of automatic configuration detection naturally limit independent functioning of the interfaces.

All interfaces support the plesiochronous data transmission. It means that reference clock frequencies, which are used to clock data transmission, can transmit data in different directions in one xDSL link.

The clock frequencies of different xDSL channels are completely independent if they do not operate in the multipair mode.

If the xDSL channel is configured to operate in the independent mode (normal settings), it can simultaneously transmit one or several E1 streams and one WAN stream. This transmission is plesiochronous. All E1 streams received by one DSL interface should use the same clock frequency in one direction.

User Manual

Table 3.1 represents line settings in the independent mode.

Table 3.8 Line settings in the independent mode.

<i>Mode</i>	<i>Coding type</i>	<i>Base rate</i>	<i>Data transmission rate</i>	<i>Standard</i>
Manual configuration, Master, Slave	PAM16	3..60	Base rate* 64 Kbit/s	Annex A, Annex B, Annex AB (auto detection)
	PAM32	12..89		
Auto detection, Master	PAM16	Auto (3..60)		Annex AB (auto detection)
	PAM32	Auto (12..89)		
Auto detection, Slave	(PAM16, PAM32)	Auto (3..89)		Annex AB (auto detection)

3.3.4.1.1 Master/Slave/Auto

To establish a connection, it is necessary that one transceiver be a **Master** and the other – a **Slave**. In this case, the connection is controlled by the Master device. The connection is not possible in the Master – Master or Slave – Slave configurations. The regenerator can also automatically detect the “Master/Slave operation modes. In this mode, the regenerator automatically detects from the side of which of line interface the Master device and the Slave modem are located.

The **MASTER ON/OFF** commands (the Configuration management menu) is used to configure the Master/Slave operation modes.

3.3.4.1.2 Multipair modes

S-Access ETHERLINK-II modems and regenerators support the multipair mode.

If 2, 3 or 4 DSL channels are configured to operate in the multipair mode, they function at the same clock frequency and line rate as one DSL channel with doubled, tripled or quadrupled transmission capacity. Similarly to the independent channel, such a combined channel can simultaneously transmit one or several E1 streams and one WAN stream. This transmission is plesiochronous. All E1 streams received by one DSL interface should use the same clock frequency in one direction.

In the multipair mode, one xDSL channel serves as a Master channel, while the other xDSL channels serve as Slave channels. If the link in one channel fails, links in all other channels break too and the procedure of connection activation starts again.

The four-channel modems provide a possibility to organize pair-wise channels, i.e., these two two-pair links will operate independently from each other.

The main application of the multipair modes is the increase in the transmission range. In this case, some channels operate at low transmission rates. Limitations are imposed on the Base rate parameter in the multipair mode. These limitations are listed in Table 3.9

User Manual

Table 3.9 Line configurations in the multipair mode.

<i>Mode</i>	<i>Coding type</i>	<i>Base rate</i>	<i>Data transmission rate</i>	<i>Standard</i>
2-pair, Manual configuration, Master, Slave	PAM16	3..60	2*Base rate* 64 Kbit/s	Annex A, Annex B, Annex AB (auto detection)
	PAM32	12..64		
2-pair, Auto detection, Master	PAM16	Auto (3..60)		Annex AB (auto detection)
	PAM32	Auto (12..64)		
2- pair, Auto detection, Slave	Auto (PAM16, PAM32)	Auto (3..64)		Annex AB (auto detection)
3- pair, Manual configuration, Master, Slave	PAM16	3..42	3*Base rate* 64 Kbit/s	Annex A, Annex B, Annex AB (auto detection)
	PAM32	12..42		
3- pair, Auto detection, Master	PAM16	Auto (3..42)		Annex AB (auto detection)
	PAM32	Auto (12..42)		
3-pair, Auto detection, Slave	Auto (PAM16, PAM32)	Auto (3..42)		Annex AB (auto detection)
4- pair, Manual configuration, Master, Slave	PAM16	3..32	4*Base rate* 64 Kbit/s	Annex A, Annex B, Annex AB (auto detection)
	PAM32	12..32		
4- pair, Auto detection, Master	PAM16	Auto (3..32)		Annex AB (auto detection)
	PAM32	Auto (12..32)		
4- pair, Auto detection, Slave	Auto (PAM16, PAM32)	Auto (3..32)		Annex AB (auto detection)

Figure 3.11 shows an example of organization of a four-pair operation mode. Four xDSL channels are combined into one group of xDSL channels, through which an E1 stream and Ethernet packets are transmitted. The use of this scheme involving the S-Access ETHERLINK-II equipment allows one to increase the transmission range, compared to the use of only one xDSL channel (the advantage in the transmission range will depend on the cable parameters and noise immunity).




Figure 3.11 Example of organization of a four-pair operation mode.

The <MULTIPAIR> command is used to configure this operation mode.

3.3.4.1.3 Reservation

Reservation is provisioned for 2- and 4-channel S-Access ETHERLINK-II devices.

The main task of reservation is to transmit the most important data even in the case of a failure of one or several DSL connections (contingency). Reservation should also provide an efficient use of the bandwidth for all DSL channels used by it in the normal mode.

Reservation is not aimed at continuous transmission of important data in the case of contingencies. When one or several DSL connections fail, a short-term loss of Ethernet packet and E1 data can occur.

DSL channels with the successive numbers, for example, DSL1, DSL2, or DSL2, DSL3, DSL4, are merged into a group of channels with reservation. For these channels the traffic with the lowest numbers has higher priority than the traffic with higher numbers. For example, DSL1 has a higher priority than DSL2, and DSL2, in turn, has a higher priority than DSL3.

In the normal mode, each channel transmits its own data as usual.

If communication is lost in one or several channels of the reservation group, other working channels transmit data of high-priority channels. Therefore, in the case of contingency the system always operates as if the low-priority channels failed.

Consider reservation with two DSL1 and DSL2 channels (DSL1 has a higher priority than DSL2). If the DSL2 channel fails, the DSL1 channel continues to operate without any changes. If the DSL1 channel fails, the DSL2 channel transmits the data of the DSL1 channel. Hence, the DSL1 channel should transmit the high-priority data.

If the substitute channel has a lower transmission capacity than the main channel, the volume of the data being transmitted over it will decrease. First, the volume of WAN data will decrease up to 1 TS, then, the number of transmitted time slots of the E1 stream will decrease, E1 being at the end of the list of E1 streams being transmitted (i.e., in the list E1-1, E1-2, the E1-2 stream will be deleted). First, time slots with large numbers are deleted. However, there is an exception for TS 16, which, if transmitted, will be deleted before or after TS 0.

Table 3.10 presents examples of reservation with two channels:

User Manual

Table 3.10 Examples of reservation with two channels.

Mode	Normal mode		DSL2 down		DSL1 down	
	DSL1	DSL2	DSL1	DSL2	DSL1	DSL2
DSL1: baserate 72, DSL2: baserate 61	E1-1, 40 TS WAN	E1-2, 29 TS WAN	E1-1, 40 TS WAN	Failure	Failure	E1-1, 29 TS WAN
Total	E1-1, E1-2, 69 TS WAN		E1-1, 40 TS WAN		E1-1, 29 TS WAN	
DSL1: baserate 72, DSL2: baserate 61	E1-1, E1-2, 8 TS WAN	61 TS WAN	E1-1, E1-2, 8 TS WAN	Failure	Failure	E1-1, 28 TS E1-2, 1 TS WAN
Total	E1-1, E1-2, 69 TS WAN		E1-1, E1-2, 8 TS WAN		E1-1, 28 TS E1-2, 1 TS WAN	
DSL1: baserate 72, DSL2: baserate 61	72 TS WAN	E1-1, 29 TS WAN	72 TS WAN	Failure	Failure	61 TS WAN
Total	E1-1, 101 TS WAN		72 TS WAN		61 TS WAN	
DSL1: baserate 89, DSL2: baserate 89	E1-1, 57 TS WAN	E1-2, E1-3, 25 TS WAN	E1-1, 57 TS WAN	Failure	Failure	E1-1, 57 TS WAN
Total	E1-1, E1-2, E1-3, 82 TS WAN		E1-1, 57 TS WAN		E1-1, 57 TS WAN	


Figure 3.12 illustrates an example of reservation for a two-channel system (according to the two last rows in Table 3.10), **X** means a contingency:

- Line rate over DSL1 and DSL2 is 89x64 Kbit/s;
- In the normal mode, the system transmits the E1-1 stream, WAN data (Ethernet) over DSL1 and E1-2, E1-3, WAN data (Ethernet) over DSL2;
- The DSL1 interface has a higher priority compared to DSL2, therefore if communication in the DSL2 channel fails (down), no reservation occurs (DSL1 Up, DSL2 Down);
-
- In the case of a contingency at the DSL1 interface (for example, loss of signal), E1-1 streams and WAN are transmitted over the DSL2 link.


User Manual

-
-
-
-
-
-
-

Normal Mode



DSL1 Up, DSL2 Down



DSL1 Down, DSL2 Up



Figure 3.12 Example of reservation.

At the same time, while for a two-channel system the replacement of channels is trivial in the case of contingency; in three- and four-channel systems different variants are possible. However, any system with the reservation mode follows a strict logic of channel substitution because by default the system operates under conditions of incomplete data transmission, i.e., unreliable communication. Therefore, below we present a table of channel reservation, which should be used by all devices in the case of contingencies.

The table for four DSL channels is constructed based on the assumption that communication is lost frequently in one channel, while communication in two channels occurs less frequently. In this case, loss of communication occurs successively, i.e., first one channel fails and then the other channel fails. Therefore, following the rules of channel substitution will allow one to minimize the number of channel substitutions (especially high-priority channels) in cases of contingencies. This will minimize the losses of data during channel switching. Tables for two and three channels are based on the same assumption, but they are simpler.

User Manual

DSL1	DSL2	DSL1	DSL2	DSL3	DSL1	DSL2	DSL3	DSL4
1	2	1	2	3	1	2	3	4
1	Down	1	2	Down	1	2	3	Down
Down	1	1	Down	2	1	2	Down	3
		1	Down	Down	Down	2	Down	Down
		Down	2	1	1	Down	3	2
		Down	1	Down	1	Down	2	Down
		Down	Down	1	1	Down	2	2
					1	Down	Down	Down
					Down	2	3	1
					Down	2	1	Down
					Down	2	Down	1
					Down	1	Down	Down
					Down	Down	2	1
					Down	Down	1	Down
					Down	Down	Down	1

Figure. 3.13 Examples of reservation of systems with two, three and four xDSL channels.

The <RESERVE> command is used to configure reservation.

3.3.4.1.4 Automatic configuration of a link

S-Access ETHERLINK-II devices allow one to configure the link in accordance with the Master-modem configuration. This mode is available for the following links:

- Point-point single-channel links;
- Point-point multichannel links with independent channels;
- Star-topology multichannel links;
- Point-point multipair links;
- Point-point two-channel two-pair links;
- Star-topology two-pair links;
- Links with regenerators.

Note: Automatic configuration of link reservation is not supported.

When the automatic configuration is used, the Slave modems and regenerators receive nearly all configuration parameters for DSL and E1 from the link. In a majority of cases they require minimum configurations, which allows one not duplicate manually configurations to all other devices in the link. Such configurations as the number of E1 time slots transmitted over DSL, CRC4 and G704 modes should not be configured on all devices because they are received automatically from the link.

User Manual

The system of automatic configuration operates as follows:

- The CP side (Slave) automatically adjusts so that to correspond to the stream structure received from the CO side (Master), and not to cause permanent losses of user data;
- If the CP side (Slave) cannot adjust correspondingly, it displays a RCONF alarm and sends a message to the remote terminal device. If configurations of terminal devices (Master and Slave) do not coincide, the RCONF alarm is displayed. RCONF stands for remote urgent alarm.

The link is adjusted to the channel structure in the direction from the Master to the Slave:

- The stream structure is configured on the Master device;
- The regenerator, which the next in the link, receives this structure and configures itself according to it;
- The next regenerator receives the structure from the previous regenerator and performs configuration according to it;
- The Slave device receives the stream structure from the regenerator, which the last one in the link, and also performs configuration;
- When the Slave device receives configuration, it distributes the received E1 streams to its E1 ports. If the number of ports is not enough, it displays the RCONF alarm and does not change the configuration of E1 streams. If the E1 streams are not distributed, the Slave device receives configurations of WAN. Therefore, the integrity of the Ethernet link is supported.

The RCONF alarm (which is displayed by the <ALARM> command and stands for the remote urgent alarm) means that the local and remote equipment have incompatible configurations. The RCONF alarm is automatically not displayed if a DSL link, in which it was detected, fails. If the device operates in the CA mode (automatic configuration of a link), the alarm is not displayed when the device finally adjusts to the CO side (Master). We consider several examples of automatic configuration of the S-Access ETHERLINK-II system.

Four fractional E1 streams and Ethernet data are transmitted over one DSL link.

User Manual




Figure 3.14 Example No. 1 of automatic configuration of a link.

The next example shows the start topology. The Master device is the center of the star, while the rays, represented by the Slave devices, are configured automatically.




Figure 3.15 Example No. 2 of automatic configuration of a link.

A more complex case is the independent two-channel connection: two E1 streams and Ethernet packets are transmitted in the first channel and the second channel. The Slave device determines the order of E1 interfaces for the streams from each DSL link only when communication in both links is established.




Figure 3.16 Example No. 3 of automatic configuration of a link.

S-Access ETHERLINK-II regenerators are configured similarly to the above examples.

3.3.4.2 E1 interface (2 Mbit/s G.703/G.704)

The operation modes described below refer to the E1 interfaces.

3.3.4.2.1 Transparent and ITU-T G.704

In the transparent mode, the E1 data will be transmitted over the DSL without any changes. **The transparent mode is only possible for transmission rates of no less than 2056 Kbit/s when transmitting one E1 stream in this mode and of no less than 4104 Kbit/s when transmitting both E1 streams in this mode.**

In the G.704 mode (framing according to ITU-T G.704), the E1 data stream is processed by the E1 framer, which is incorporated in the block of E1 network interfaces. In this case, from 1 to 32 time slots of the corresponding E1 stream can be transmitted over the DSL line.

The **G704 OFF/ONN** command (the Configuration management menu) is used to enable/disable the Transparent/ITU-T G.704 modes.

3.3.4.2.2 CRC4 (cyclic redundancy check)

The CRC4 mode enables the error performance monitoring of the E1 network interface with the help of a cyclic redundancy check.

If the mode is enabled, the modem synchronizes with CRC4 sub-multiframes at the E1 output and displays information about CRC errors. In this case the modem regenerates E1 CRC4 sub-multiframes and checksum words in the outgoing E1 stream.

If the mode is disabled, the modem transmits transparently CRC4 sub-multiframes and checksum words in the case if the generation of the zero time slot is deactivated. If the TS0GEN mode is activated, the zero time slot is generated without CRC4 sub-multiframes and checksum words.

3.3.4.2.3 AIS Generation (alarm indication signal)

If this mode is enabled, AISs will be transmitted to the E1 side under the following conditions:

- the loss of the line signal from the remote device or loss of frame alignment on the DSL side;
- the remote device receives an AIS over E1 interface, which is configured to transmit data from E1 to DSL. This mode is enabled if only the AIS Detection mode is enabled on the remote device (see below). If modems (A and B) transmit two E1 streams, then if AIS is received over the first E1 channel of the A modem, in the B modem the AIS will be generated over the first channel. And if AIS is received over the second E1 channel of the A modem, in the B modem the AIS will be generated over the second channel.

The **AISGEN ON/OFF** command (the Configuration management menu) is used to enable/disable the AIS Generation mode.

Warning! If the AIS Generation mode is disabled, the signal at the output of the E1 interface will be absent in the case of losing communication in the DSL line (except for time slots of this interface dedicated to carry Ethernet data).

Warning! If a part of time slots of one of E1 network interfaces is used to transmit Ethernet data, AISs will not be generated for this interface.

3.3.4.2.4 AIS Detection

If this mode is enabled, the receiving of AIS over the E1 interface will cause the following:

- a non-urgent alarm will appear;
- AIS will be transmitted to the remote device of the DSL.


User Manual

The **AISDET ON/OFF** command (the Configuration management menu) is used to enable/disable the AIS Detection mode.

Warning! It is recommended to enable the AIS Detection and AIS Generation modes.

3.3.4.2.5 E1 clock modes

Figure 3.17. E1 clock modes



The following sources can serve as reference timing signals for a device with the E1 network interface in the xDSL direction:

1. An external generator (for Sub Rack S-Access ETHERLINK II devices) (**EXTERNAL**).
2. A signal from the first input E1 stream (**E11**) (in its presence).
3. A signal from the second input E1 stream (**E12**) (in its presence).
4. A signal from the third input E1 stream (**E13**) (in its presence).
5. A signal from the forth input E1 stream (**E14**) (in its presence).
6. A signal from the internal generator (**INTERNAL**).

The user can configure the priority levels for clock sources using the **SETCLOCK** command. The device automatically switches to the clock source with the highest priority under conditions that synchronization in this mode is possible.

EXTERNAL means synchronization from an external generator having the parameters corresponding to ITU-T Rec. G.703.10. If the input signal of the external clock is lost, the device switches to another clock source according the priority level. When configuring synchronization, this external clock should have the highest priority. If the external generator is absent, it should not be included in the priority list.

Note: Stand alone and MiniRack devices cannot use an external clock source.

E11, E12, E13 and E14 mean synchronization from one of the input E1 stream. If the stream, which serves as a clock, is lost, the device switches to another clock according to the priority level. These clocks should be listed as the second, third, fourth and fifth clocks in the priority list, if the external clock generator is used. Otherwise, they will serve as primary clock sources and be listed as the first, second, third, fourth and fifth ones, respectively, in the priority list, if the external clock generator is absent.

INTERNAL means synchronization from an internal clock source. This clock source should be the last one in the priority list (but in the absence of other clock sources, for example, when only Ethernet data are transmitted, this source can be the primary and the only one).

Switching between clock sources occurs within 100 ms, after synchronization is lost.

3.3.4.3 Ethernet interface

S-Access ETHERLINK II devices have an IEEE 802.3 interface to connect local Ethernet networks.

The Ethernet networks use the method for access to the data transmission medium, which is called carrier-sense-multiply-access with collision detection (CSMA/CD).

Modems and regenerators of the S-Access ETHERLINK II family supports the VLAN protocol (Virtual Local Area Network – IEEE 802.1Q).

A virtual network represents a group of network nodes, whose traffic, including the broadcast traffic, is completely isolated from other network nodes.

This means that the frame transmission between different virtual segments by using MAC address is impossible independent of the type of the address, i.e., unique, group or broadcast one. At the same time frames are transmitted within the virtual network by using the Ethernet switching technique. By using the VLAN protocol one can unite the network users into separate logic groups, for example, in order to decrease the traffic load in the network, to improve the safety and to simplify management.

Organization of virtual networks allows one to decrease the load in the network, because the broadcast traffic will be transmitted not to the entire network but to members of the VLAN sender.

Due to the fact that the members of different VLANs can exchange information via a router, which allows the traffic to be controlled rather simply, the use of VLANs provides a high level of security.

In addition, introduction of changes in the network structure is simplified because one should configure the modem port instead of configuring the work station to which the modem is connected.

To construct VLAN networks and to provide the priority in the data transmission, an extended Ethernet frame is used, which contains an additional VLAN tag of length of 2 bytes. The tag includes the number of the VLAN to which the packet belongs and its priority level.

Some types of traffic should be sent via the network without any delays, for example, real-time video at video conferences or IP traffic. To provide the necessary quality of this traffic, the devices support the Ethernet traffic priority according to the IEEE 802.1P protocol, the so-called QoS (Quality of Service) method. Analyzing the content of the header of the Ethernet frame, the internal switch obtains information about the necessary priority of this application and places data to the corresponding queue of the output port. The S-Access ETHERLINK II equipment supports two priority queues when sending packets – a high priority queue and a low priority queue. According to it, all Ethernet traffic can be divided into groups of high priority (for example, VoIP traffic transmission, or control and management channel) and groups of low priority (for example, LAN1 and LAN2).

Devices of the S-Access ETHERLINK II family support two types of VLANs:

User Manual

- Port-Based VLAN (VLAN switching at port level). VLAN numbers and QoS priorities are assigned to ports (see below);
- Address-Based VLAN (VLAN switching at the level of MAC addresses). A static table of special MAC addresses is organized (see below).

All Ethernet traffic is distributed by the internal Ethernet switch between network interfaces of the device (see Figure 3.18).

There exist four types of network interfaces of S-Access ETHERLINK II devices:

1. Ethernet interface (external connector on the front panel).
2. xDSL interface (when the device is properly configured).
3. One of E1 interfaces (when the device is properly configured).
4. Virtual management port (Telnet session).





Figure 3.18 Internal Switch.

The number of network interfaces Ethernet, E1 and xDSL depends on the model of the device. A 4-port Ethernet switch is embedded in the printed board of LTUs. In the software of S-Access ETHERLINK II devices of the V9 type, the group of physical ports ETH1, ETH2, ETH3 and ETH4 is combined logically into one LAN port (VLAN tag, TRUNK/ACCESS, QoS, priority queues of Ethernet packets), the configuration being performed simultaneously for physical Ethernet ports.

The choice of the interface (DSL, or E1), which will be mapped to the corresponding WAN interface, is performed by the `<PAYLOAD>` и `<WANTS>` commands.


User Manual

The DSL channel is strictly mapped on WA1 for single-channel modems, while the E1 interface is strictly mapped on WA2 (see Figure 3.19).



*Figure 3.19 Internal Switch for single-channel devices
(for example, SA-PAM-SAN-E1B/Eth, V50).*

For generators, the internal Ethernet switch has two WAN interfaces (WAN1 for DSL1, WAN2 for DSL2), one LAN interface and an internal management interface INT. E1 interfaces on regenerators are not provisioned (see Figure 3.20).



*Figure 3.20 Internal Switch for single-channel regenerators
(for example, SA-PAM-RGN-Eth-PL, V56).*

User Manual

A group of LAN Ports (Ethernet interface) means that a connector (or connectors) is located on the front panel of the device. This port can serve both as a **Trunk port** and an **Access port**.

The **Trunk port** is a port at the input and output of which all present packets have the VLAN format, namely, the Ethernet frame with a header, determining the number of the VLAN and QoS (Quality of Service) to which the IP packet belongs. Special equipment, which supports the VLAN, is connected to the Trunk port. A PC with a standard network interface card cannot be connected to the Trunk port.

The **Access port** is a port at the input and output of which all present packets have a standard Ethernet format (without the additional two bytes for the header). A PC with a standard network interface card can be connected to the Access port.

Ethernet packets of the VLAN format are always transmitted over the xDSL or E1 interfaces in S-Access ETHERLINK II devices. In this case, the data of Access ports are first transformed into Ethernet packets of the VLAN format according to the specified rules and then are transmitted over the line interface.

A VLAN number and a QoS priority level, which are used by default to convert Ethernet packets into the VLAN format, are assigned to the **Access port**. In addition, every unit contains a table of static MAC addresses of devices, so that each device can have a VLAN number and a QoS priority level (a table of special MAC addresses). This table can contain up to 8 MAC addresses. If a packet is received from the Access port, and the MAC address of the packet sender is in this table, a header with the necessary VLAN number and the QoS priority will be assigned to this packet before transmitting it to the Trunk port. Otherwise, a default VLAN number and QoS priority will be assigned to the packet.

Physical ports (if there are some of them) are united into a LAN group in the device software. All physical Ethernet interfaces (the LAN group) have identical VLAN and QoS settings. A possibility is also provisioned to configure separately the transmission rate and duplex for each physical interface (ETH1 – ETH4).

A group of DSL ports (WAN1 – WAN4) (xDSL interface) means that Ethernet data can be mapped onto the specified time slots of the xDSL interface by using the switch of 64 Kbit/s time slots. In this case, this port always serves as a **Trunk port**, i.e., data received from **Access ports** are first transformed into Ethernet packets of the VLAN format according to the rules specified and then are transmitted over the xDSL interface.

A group of E1 ports (WAN1 – WAN4) (E1 interface) means that that Ethernet data can be mapped onto the specified time slots of the E1 interface by using the switch of 64-kbit/s time slots. In this case, this port always serves as a **Trunk port**.

A virtual management port (INT) (Virtual management port) is an internal device management program. IP-address of this device is the logical address of the management program. For example, to open a session for managing a remote device (i.e., to exchange data between a control and management PC and the device program), the IP-address of this device should be specified in the Telnet program. At the physical layer, the MAC address of the device is also the management program address, which is contained in the Ethernet frame.

Note: As a rule the data of the management port have the highest priority (for example, QoS = 7).

3.3.5 An integrated switch of 64-kbit/s time slots

3.3.5.1 E1 mode (transmission of only time slots of E1 streams)

In this mode, only time slots of E1 streams are transmitted over xDSL lines.

Time slots of the E1 stream are transmitted in the xDSL frame according to ITU-T Rec. G.991.2. The table presented below contains examples of the correspondence between the data transmission rates for a modem and transmitted time slots of the E1 stream for this transmission mode.

User Manual

Table 3.11 Examples of the correspondence between the data transmission rates for a modem and transmitted time slots of the E1 stream for this transmission mode in a single-channel device.

<i>Time slots of E1 streams (first E1/second E1)</i>	<i>Total number of transmitted time slots</i>	<i>Minimal transmission rate in the line required for transmitting this number of time slots (Kbit/s)</i>
0,1,16/0,1,2,3	7	456
0,1,2,3,31/none	5	264
0-29,31/ none	31	1992
0-31/0-31	64	4104

3.3.5.2 Mode of simultaneous transmission of time slots of E1 and Ethernet data

The system supports simultaneous transmission of time slots of E1 streams and Ethernet data (from the ports WAN1, WAN2, WAN3, WAN4, and the internal Ethernet switch) into an xDSL stream, i.e., the mode of time slot multiplexing from E1 and Ethernet network interface in the xDSL stream.

When E1 and Ethernet data are transmitted simultaneously, the distribution of xDSL time slots is performed as follows:

- time slots of the first E1, chosen for transmission in the line interface in the ascending order, are transmitted in time slots from 0 to m_1-1 ;
- time slots of the second E1, chosen for transmission in the line interface in the ascending order, are transmitted in time slots from m_1 to m_1+m_2-1 (for Sub Rack and MiniRack devices);
- Ethernet data are transmitted in time slots from m_1+m_2 to $n-1$.

Here,

- n is the total number of transmitted xDSL time slots;
- m_1 is the number of time slots from the first E1 selected for transmission into xDSL;
- m_2 is the number of time slots from the second E1 selected for transmission into xDSL;

Note: A part of time slots of one of E1 interfaces can be used to transmit data from the WAN2 port of the internal Ethernet switch.





Figure 3.21 Example of distribution of time slots in an xDSL frame at a line rate of 89x64 Kbit/s in the mode when both E1 interfaces and both internal WAN1 and WAN2 ports are used for the termination device.

3.3.6 Test loops

To simplify the device start-and-adjustment, the system provides activation of test loops on E1 interfaces or the line interface of the device.



Picture 3.22. Test loops

Test loops can be activated for the Master and Slave devices as well as for the regenerator.

The **LOOP1 ON/OFF N** command is used to activate/deactivate LOOP1, where **N** is the number of the network interface.

User Manual

LOOP2 M:N, where **M** is the number of the line interface and **N** is the number of the regenerator, can be activated **only remotely**. This command allows one to activate remotely a loopback to the device, from which the command was sent. It means that if LOOP2 is activated remotely by the Master device, the data will be looped back by the Slave device to the Master-device side, and vice versa.

Warning! When activating LOOP2 under conditions that xDSL is used to transmit Ethernet data, it is necessary that the device is disconnected from the Ethernet network!

3.3.6.1 Analog Loopback

During the analog loopback test, the xDSL receiver receives the transmitted signal from its own transmitter.

The analog loopback function is used to test the equipment itself.

Warning! To perform the analog loopback, the cable should be disconnected from the unit!

The **STARTAL** command is used to activate the analog loopback.

All data of the network interface is looped back according to the configurations of this interface.

The analog loopback causes a non-urgent alarm of the local unit and an urgent alarm of the remote unit.

3.3.6.2 Performance monitoring

The transmission performance of a link can be monitored in two different ways. The signal quality is typically used during installation and maintenance procedures, whereas the G.826 error performance parameters are used for long term evaluation of operating links and during acceptance testing.

The Noise Margin (NM) provides qualitative performance information of a specific link. The **NM** command is used to activate this test. This parameter is calculated according to G.991.2 and is an efficient tool for determining the qualitative performance of an xDSL link.

During acceptance testing, it is recommended to set the line rate or choose cable pairs (at a fixed line rate) so that the NM value be no less than 6 dB.

An NM of 0dB in the presence of a Gaussian noise would yield an expected Bit-Error-Ratio of 10^{-7} .

3.3.6.3 G.826 performance monitoring

The error performance monitoring of a digital DSL link is performed according to ITU-T Rec. G.704. The evaluation of the G.826 error performance parameters is based on CRC (Cyclic Redundancy Check) error detection.

User Manual

CRC generation and detection are performed separately for the E1 interfaces and xDSL interfaces.




Figure 3.23 G.826 performance evaluation.

On the E1 side, four CRC4 check bits are generated per sub-multiframe (SMF) and compared with the corresponding bits of the next SMF. If they do not match, the CRC4 error counter is incremented.

On the xDSL side, six CRC6 check bits are generated per xDSL frame.

CRC6 errors are used by the software to count the block errors of the xDSL channel and to evaluate its error performance according to ITU-T Rec. G.826.

For the E1 interface, calculations according to G.826 are only possible in the framed mode according to G.704 with the CRC4 option enabled. In the framed mode with the CRC4 option disabled, only FAS errors are detected.

The estimation of a bit-error rate is not within the scope of G.826 calculations.

The **G826** and **G826 E1** command (the Performance management menu) are used to view the G.826 error performance statistics.

3.4 Alarm indication

3.4.1 LEDs

The LEDs are used to display normal operation conditions and alarm conditions of a device.

For NTUs and regenerators in the plastic housing:

DSL 1 – a LED showing the status of the first line interface;
DSL 2 – a LED showing the status of the second line interface;
Eth – a LED showing the status of the Ethernet interface;
G.703 1 – a LED showing the status of the first E1 interface;
G.703 2 – a LED showing the status of the second E1 interface;
DSL* - LEDs showing the status of line interfaces at connectors;
Eth* - LEDs showing the status of the Ethernet interface at the connector;
E1* - a LED showing the status of E1 interfaces at connectors.

For LTUs:

"1" – a LED showing the status of the local unit;
"2" – a LED showing the status of the remote unit;
"3" – a LED showing the status of the first E1 interface;
"4" – a LED showing the status of the second E1 interface;
"5" – a LED showing the status of the third E1 interface;
"6" – a LED showing the status of the fourth E1 interface;
DSL* - LEDs showing the status of line interfaces at connectors;
Eth* - LEDs showing the status of the Ethernet interface at the connector.

For Minirack devices:

DSL* - LEDs showing the status of line interfaces at connectors;
Eth* - LEDs showing the status of the Ethernet interface at the connector;
E1* - a LED showing the status of E1 interfaces at connectors.

User Manual

Table 3.12 “The device statuses according to the statuses of LEDs”.

Device status	LED status			
	«1»	«2»	«3» , «4», «5» , «6», G.703 1, G.703 2, G703*	DSL 1; DSL2; DSL *
Power failure or power is off	Off	Off	Off	Off
Hardware or software failure	Red blinking	Off	Off	Off
Normal operation	Green	Green	Green	Green
Non-urgent alarm ("1" - local; "2" – remote)	Amber	Amber	-	-
Urgent alarm ("1" - local; "2" – remote)	Red	Red	-	-
Non-urgent alarm at the E1 interface	-	-	Amber	-
Data of the E1 interface are not used for transmission into the line interface or for Ethernet data transmission	-	-	Off	
Urgent alarm at the line interface	-	-	-	Red

Table 3.13 The device statuses corresponding to statuses of Ethernet LEDs”.

LED	LED status	Device status
Ethernet (left LED) or Eth	Green blinking	Data receive and/or transmit, half-duplex
	Red/Amber blinking	Data receive and/or transmit, duplex
	Off	Connection is not active
	Red blinking	Collisions
Ethernet (right LED)	Green	100 Mbit/s receive/transmit rate
	Off	10 Mbit/s receive/transmit rate

When managing the device via the RS232 interface or via Telnet, all LEDs, except for Ethernet LEDs, blink with a frequency of 1 Hz.

3.4.2 Alarm LEDs

If an alarm appears on any of ETHERLINK II devices (Master or Slave), the alarm LEDs are lit with red or amber.

The Table below presents alarm conditions with the help of alarm LEDs:

Table 3.14 "Alarm LEDs of an ETHERLINK II device".

Name	Group	Alarm status	1	2	3,4,5,6	DSL1 DSL2	DSL *	Description
LOS	DSL	Urgent	R	R		R	R	Loss of signal in an xDSL link
LOSW			R			R	R	Loss of frame alignment in an xDSL link
LOSD				R		R	R	Loss of signal at the remote xDSL side
BER-H			R			R	R	Block-error-rate in an xDSL line according to G.826 $\geq 30\%$
SEGD				R		R	R	Loss of signal or an alarm on a regeneration segment (segment degradation)
ALB		Urgent + non-urgent	A	R		A	R	xDSL analog loopback is activated
SEGA		Non-urgent		A		A	R	Data errors or loss of frame alignment on a regeneration segment (segment alarm)
LOOP2				A		A	R	Loop is activated from the remote device to the local device
LOS-S					A			Loss of signal on the E1 side
LFA-S					A			Loss of frame alignment on the E1 side
AIS-S					A			Receiving AIS on the E1 side
BER-S					A			Excessive block error rate on the E1 side
LOOP1					A			Loop is activated towards the E1 equipment
AIS-R				A				Receiving AIS on the E1 side of a remote device
HW-F	Maintenance		R B					Hardware failure

User Manual

RCONF			R					Configuration of the remote device is not compatible with the configuration of the local device (for example, the local device is configured to transmit Ethernet data, while the remote device is configured to transmit two E1 streams)
DSL-F			R B					DSL signal processor initialization failure

“A” – amber LED

“R” – red LED

“RB” – red LED blinking

3.5 Management of S-Access ETHERLINK II devices

The equipment has integrated functions of management and diagnostics. S-Access ETHERLINK II devices can be connected to the terminal by using the RS232 interface or to a PC with the VT100 terminal. In addition, devices can be connected to a PC network card or the Ethernet network, to which the computer is attached. In this case, the Telnet session is used to manage the equipment, the WEB interface being used to display the statistics.

The management and diagnostics functions allow one to configure devices and to receive additional information, such as parameters of an xDSL link quality or G.826.

3.5.1 Management of S-Access ETHERLINK II devices with the help of the RS232 interface

3.5.1.1 Management of S-Access ETHERLINK II Sub Rack devices

The rear panel of the AccessGain shelf contains the TTL management bus which is organized according to the “point / multipoint” scheme. The TTL-RS232 converter and a terminal connector are on the rear panel of the shelf. If the ACU unit is used, the management connector is on the front panel of this device.

Use the standard RS232 cable to connect the terminal. While attaching the cable to the computer COM port, make sure that the port is not occupied by the other device drivers (for example, mouse). Table 3.15 presents the pin assignment.

Table 3.15 Pin assignment of a standard RS232 cable.

<i>DB9, male (shelf side)</i>	<i>DB25, female (computer side)</i>	<i>DB9, female (computer side)</i>
2	3	2
3	2	3
5	7	5

The terminal must be configured in the following way:

- Transmission rate: 9600 Kbit/s;
- transmission format: 8-N-1;
- flow control: NONE;
- terminal type: VT100.

At any one time only one device in the shelf can be logically connected to the management interface.

The device is chosen in accordance with the slot number, in which it is mounted. To select the necessary device, input `<%SN>`, where SN is the slot number.

Example: to select the unit, mounted in slot 3, type:

`%03.`

The unit in the shelf displays `%SN` after the ECHO command is entered, where SN is the slot number.

After typing “ECHO”, the operator will receive a response from LTU devices, as it is shown below:

```
ECHO.
01 02 08 10 11 12
```

3.5.1.2 Management of S-Access ETHERLINK II MiniRack and Stand Alone devices

The management terminal is connected to the **MONITOR** connector, which is either on the front or the rear panel of the device. The requirements to the terminal configuration are similar to those of Sub Rack devices. After the power supply is switched on, press Enter. The PC will display the main management menu.

3.6 Management of S-Access ETHERLINK II devices with the help of the Ethernet interface

3.6.1.1 Management of S-Access ETHERLINK II devices with the help of the Telnet session

The front panel of S-Access ETHERLINK II devices contains the Ethernet connector. The local network containing the management computer (or the PC itself) can be connected to this connector.

Management is performed by using the Telnet session activated by a standard command:

```
telnet <IP-address>
```

in Windows 95 or above. (Any other program can be used to open the Telnet session if it supports this protocol.)

The TELNET session is used to configure modems remotely as well as other devices connected to the MONITOR bus of the same AccessGain shelf to which the modem is connected.

After opening the TELNET session, the user authentication is performed. Two types of users are used: "admin" users, who can change configurations and "user" users who can only view parameters and statistics. Initially passwords are empty; authentication in this case is not performed and users automatically have the administrator rights. Only "admin" users can set passwords for both types of users.

If authentication is successful, the modem main menu is displayed. If authentication fails, it is repeated up to three times, and after it the connection breaks.

For Sub Rack devices at any time except for the moment when the password is entered in the Telnet session, the command for choosing devices to manage %NNN is available (NNN are digits and symbols of the Latin alphabet in the range from 0 to 80). This command is used to configure S-Access ETHERLINK II Sub Rack modems as well as other devices connected to the same MONITOR bus (i.e., installed in the same shelf).

To clear the screen and to establish connection with the Monitor bus used to manage the cabinet (chassis, shelf, rack), the <␣%1␣> command is used. This command is used to send the ECHO command.

User Manual

First, the bus is checked whether it is occupied by another device, for example by the second S-Access ETHERLINK II modem. If the bus is busy by another device, the following message is displayed:

```
"ERROR: Console is busy."
```

If this message is displayed, enter the next command % to choose the device.

To clear the screen, to connect the device to the Monitor bus and then to configure the unit, which is in this shelf, enter the command

```
↓%1XXXX↓.
```

In this case, the ?↓%XXXX↓ command is sent to the Monitor bus (symbols "?↓" are necessary to complete the command, which probably was already entered over the MONITOR bus). Here, XXXX are digits or letters of length up to 79 symbols. (The modem does not check the correctness of XXXX.)

While configuring any device connected to the MONITOR bus, enter the ↓%↓ command to return to the mode of device management for which the TELNET session is open.

During the connection of the telnet session to the rear panel, all data are transparently transmitted to the rear panel including the % command, i.e., when the %↓ command is entered, symbols '%' and line feed are sent to the rear panel. And only after this, disconnection from the rear panel is performed.

The symbol % received from the rear panel in the mode of connection of the telnet session to the rear panel is not processed (it is translated to the telnet).

If no symbols are received by the modem over the telnet connection within 5 minutes, this session breaks and if necessary, the modem is disconnected from the Monitor bus.

For example:


User Manual

Figure 3.24 Example of remote configuration of devices via the Ethernet interface of the S-Access ETHERLINK II device.

To manage devices via TELNET, it is necessary:

- to open the TELNET session for the S-Access ETHERLINK II device. Perform authentication (enter the unit with the admin rights);
- to access the IAD№1 unit, enter %105;
- to access the Plex unit, enter %107;
- to access the RGN unit (IAD and RGN are units of the xDSL ETHERLINK family), enter %10510;
- to access the IAD№1 unit, enter %105120.

3.6.1.2 WEB interface

The WEB interface is used to display statistics when the S-Access ETHERLINK II device is connected to the management computer via the Ethernet interface. Any WEB browser is used to access the WEB interface of the S-Access ETHERLINK II device (the WEB browser is installed on a user PC and is used to search and display information in the network). To display the WEB browser, you should enter <http://X.X.X.X/>.

Here, X.X.X.X is the IP-address of the device.

After the connection with the WEB interface is established, the active window of the browser displays the following statistics:

User Manual




Figure 3.25 WEB interface – “Table of alarms of the S-Access ETHERLINK II device”.




Figure 3.26 WEB interface – “Table of G.826 error performance parameters according to ITU-T G.826”

User Manual




Figure 3.27 WEB interface – “Table of xDSL performance parameters S-Access ETHERLINK II devices”.




Figure 3.28. WEB interface – “Table of E1 statistics (according to ITU-T G.826) for S-Access ETHERLINK II devices”.

User Manual




Figure 3.29 WEB interface – “Table of TCP/IP, ICMP statistics”.




Figure 3.30 WEB interface – “Table of LAN (Ethernet), WAN1 and WAN2 statistics”.

User Manual

More detailed information about statistics and alarm statuses of the device is presented in Section 4.6.2 of the present document. All the tables displayed are dynamic. The parameters in the tables are refreshed every 5 seconds.

Click the button in the left part of the window of the WEB browser to display the necessary table. The software version is also displayed in the left part of the window.

3.6.1.3 Management of S-Access ETHERLINK II devices with the help of SNMP

The SNMP protocol is used to monitor statuses, to configure and manage S-Access ETHERLINK II devices. In this case, the control computer should have a special SNMP program installed.

S-Access ETHERLINK II devices support SNMP v1.

The following management information bases (MIBs) are supported:

- RFC1213-MIB – a standard MIB for all devices, supporting MIB II and described in RFC-1213, is fully supported.
- IF-MIB – MIB descriptions of interfaces, described in RFC-2863, are fully supported.
- S-ACCESS-MIB – a MIB for the S-Access equipment, is fully supported.
- DS1-MIB – a MIB describing E1 streams, RFC-2495, is partially supported.
- HDLSL2-SHDSL-LINE-MIB – a MIB describing xDSL-links is partially supported.

Traps are sent by the device into two addresses. The following traps are supported:

- coldStart (RFC1215).
- authentication Failure (RFC1215).
- linkUp (RFC1213-MIB, IF-MIB).
- linkDown (RFC1213-MIB, IF-MIB).
- dsx1LineStatusChange (DS1-MIB).

The SNMP protocol to be operable, the SNMP agent should be installed. The COMMUNITY command (configuration of the community parameter of SNMP messages) and the TRAPIP command (configuration of IP-addresses for traps) are used to configure the SNMP agent. The IP-address and other network configurations of the SNMP agent coincide with network configurations of the device (see SETIP, NETMASK, GATEWAY commands and the NET sub-menu).

The content of this label is described by the S-Access-MIB. By using the variables described in the S-Access-MIB, one can perform the following actions:

- to view general information about the device.
- to monitor the general status of the device (presence of alarms).
- to reboot the device.
- to configure the device, to control configurations (use, acknowledge), backup configurations and restore configurations.
- to view and clear G.826 statistics for E1 and DSL.
- to view alarm statuses.


User Manual

Every variable of the S-Access-MIB, as well as of other MIB files has a detailed description in the MIB file itself.

One can receive the S-Access-MIB via the WEB interface:

<http://X.X.X.X/S-Access.mib>.


Here, X.X.X.X is the IP-address of the device.



The screenshot shows a window titled 'commonInfo' with a toolbar containing icons for check, close, pause, abort, refresh, print, zoom, save, and help. Below the toolbar is a table with the following data:

model	SA-PAM-SA2N-2E1B/Eth
id	NTU MASTER
hardwareVersion	1.0
softwareVersion	1.1.4
softwareDate	26.7.2006
moduleType	standalone-small
subrackAddress	0
errorCode	0

Figure 3.31 SNMP– “Information about the device”.



The screenshot shows a window titled 'G826Entry' with a toolbar containing icons for check, close, pause, abort, refresh, print, zoom, save, and help. Below the toolbar is a table with the following data:

q826Id	q826Index	q826Name	q826EB	q826ES	q826SES	q826BBE	q826AvailableTime	q826UnavailableTime	q826StatReset
1	5	DSL1 CRC6	0	0	0	0	0	24	read/value
2	6	E1-1 CRC4	0	0	0	0	0	29	read/value
3	6	E1-1 E-8it	0	0	0	0	0	29	read/value
4	7	E1-2 CRC4	0	0	0	0	0	29	read/value
5	7	E1-2 E-8it	0	0	0	0	0	29	read/value

Figure 3.32. SNMP – “G.826 statistics”.

3.7 Installation

3.7.1 Installation of a shelf

The shelf is installed into a 19" standard cabinet by fixing it with screws to the rails of the cabinet (the screws are provided in the installation accessories).

3.7.2 Connection of the power and grounding cables

The power and grounding cables are connected to the SA-R-W or SA-R-PCM/W shelves according to the scheme presented in Figure 3.33.




Figure 3.33. Connection of the shelf.

The negative wiring terminal of the primary power supply source is connected to the “-48 A” terminal of the shelf while the negative wiring terminal of a standby power supply source is connected to the “-48 B” terminal. If the standby source is not used, the terminals “-48 A” and “-48 B” can be combined. The positive wiring terminal of the primary power supply source is connected to the “0V” terminal (if a standby power supply source is used it is connected to the “0V” terminal as well).

The grounding cable from the “GND” terminal is connected to the grounding bolt, which in turn, is connected to the protection ground of the office with the help of a copper conductor with the cross section area of no less than 4 mm² (the wire diameter being approximately equal to 2,3 mm).

Warning! The “0V” and “GND” terminals should be combined.

Warning! It is strictly prohibited to run the equipment until it is properly grounded!

Warning! When using SA-R-W-E or SA-R-PCM/W-E shelves of new generation, the connection is performed according to the description of the shelf.

3.7.3 Installation of SubRack devices

Sub Rack devices are mounted into slots of the shelf along the rails so that the mail connector on the rear panel of the device enters the corresponding female connector of the shelf.

3.7.4 Cabling

After devices being installed, cabling should be performed.

Cables should be reliably fixed to the corresponding connectors of the devices.

All cable connectors with screw fixing should be screwed to the corresponding connectors of the device.

Cabling should be performed as follows:

- connect E1 cables;
- connect Ethernet cables;
- connect DSL cables;
- connect the chassis signaling to the ACU unit if necessary.

3.7.5 Connection of line cables

Line cables are connected to the “xDSL” connector of the S-Access ETHERLINK II device.

3.7.6 Connection of the terminal

The management PC (the terminal) should be connected to the protection ground!

The terminal can be connected to the **DB-9 (female)** connector on the rear panel of the shelf or to the **ACU** unit for Sub Rack devices or to the **Monitor** connector for MiniRack and Stand Alone devices.

In the case, if the **ACU** unit is installed into the shelf, the connector on the front panel of the ACU unit is used for connecting the terminal. Detailed information about ACU units is presented in the “User’s guide” describing them.

3.7.7 Switching the equipment on

Before switching on the equipment make sure the power supply and grounding are properly connected.

After it, check the value of the feeding voltage and switch on the shelf or units (for Stand Alone or MiniRack devices). Control the statuses of LEDs.

3.7.8 Establishing communication

To control communication, activate the <ALARM T> command on the S-Access ETHERLINK II device. The communication is established if the <LOS> LED is off. The <SEG-D> LED helps determine the establishment of communication.

If communication is reliable, “DSL*” LEDs will be off, while for NTU devices “DSL1” (“DSL2”) LEDs will be green.

Communication is not reliable:

- if the LED color changes from green to amber and red and vice versa.
- if <BER-H> and <LOSW> LEDs change their statuses in the alarm trace mode.
- Other reasons may as well cause unreliable communication, for example:
- a breakdown of one of wires of the twisted-pair cable;

User Manual

- critical parameters of the line;
- a high level of noise in the line.

If communication between modems is not established within 5 minutes, the most probable reason for this is improper cabling or configurations of the units.

3.7.9 Error parameter control and control of line parameters

After the equipment starts communicating, one should control error parameters and line parameters. The following actions should be performed:

- to control the line parameters of ETHERLINK II devices by using the <STATUS> command;
- to clear G.826 parameters by using the <RESETG826> command;
- to measure G.826 parameters every half an hour.

Based on the line parameters and 30-minute measurements, the preliminary evaluation of the quality and reliability of the organized digital channel is performed.

The following criteria are used for evaluation:

- ES should be equal to 0;
- the NMR parameter of both S-Access ETHERLINK II devices (Master and Slave) should not be less than +8 dB.

If any of the above criteria is not fulfilled, perform the test again. But even if the second test fails, improve the quality of the line according to recommendation presented in Table 1.16.

Table 3.16. Improvement of the line quality.

<i>Unsatisfied conditions</i>	<i>Probable reasons</i>	<i>Actions</i>
1. ES should be equal to 0.	1. Improper cabling (both in the junction boxes and internal connections of the equipment).	Check the connection of line cables in junction boxes. Check internal cabling of the equipment.
	2. High level of pulse interferences and noises in the line.	Check the grounding of the equipment. Eliminate the source of interferences and noises.
	3. Faulty module.	

User Manual

2. The NMR parameter of both S-Access ETHERLINK II devices (Master and Slave) should not be less than +8 dB.	1. High attenuation in the cable caused by a cable defect.	Check attenuation in the cable. Remedy the defect.
	2. High working attenuation of the pair.	Use additional shielding of line cables of the equipment. Decrease the line rate.
	3. Faulty module.	Change the module.
	4. Improper cabling (both in junction boxes and internal connections of the equipment).	Check the connection of line cables in junction boxes. Check internal cabling of the equipment.
	5. Improper grounding of the equipment.	Check the grounding of the equipment.

3.7.10 Programming the parameters of E1 interfaces

After the equipment is started and the line parameters are checked, configure network interfaces of S-Access ETHERLINK II units.

During configuration, follow the rules:

- if the line rate is less than 2056 Kbit/s, activate the frame mode;
- if the line rate is higher than 2056 Kbit/s but slower than 4104 Kbit/s, the G.704 frame mode can be deactivated only for one of E1 interfaces;
- if the G.704 frame mode is used, the terminal E1 equipment should support this mode;
- if the G.704 frame mode is used, the settings of CRC4 parameters of the E1 line termination equipment and line channel equipment should coincide;
- AISDET and AISGEN modes are recommended to simplify the configuration of the channel;
- the system should be organized taking into account the entire requirement to synchronization.

3.7.11 Measuring the parameters of the organized digital line

The digital line parameters are measures by using special testers of the E1 stream. In this case, the tester should be also grounded.

During testing, the operation modes of testers and devices should coincide.

If the measured parameters are not satisfactory, check the regeneration segments of the line and remedy the defects.

3.7.12 Connecting the line terminal equipment and checking its operation

Connect the E1 line termination equipment to the "G.703" connector of the device.

User Manual

Before checking the operation of the whole system, make sure that the operation modes of the devices and E1 equipment coincide as well as all the requirements to synchronization are fulfilled.

3.7.12.1 Connection of Ethernet

The “Ethernet” connector on the front panel of the device is used to connect a PC, which is employed to manage equipment via Telnet or Ethernet. This connector represents a HUB connector. It means that a straight-through Ethernet cable is used to connect the ETHERLINK II device to the Ethernet switch while a crossover cable is used to connect the ETHERLINK II device to the management PC. Table 1.17 presents pinouts of a crossover cable.

Table 1.17. Pinouts of a crossover cable.

<i>Connector to ETHERLINK II</i>	<i>Connector to Switch</i>
1	3
2	6
3	1
6	2

4 PROGRAMMING GUIDE

4.1 Command structure

The command structure conforms to the ITU-T M.3400 Rec. for the telecommunication management networks:

Table 4.1 Command structure.

<i>Sub-set</i>	<i>Short-form</i>
Performance management	PM
Fault and maintenance management	FMM
Configuration management	CM

User Manual




Figure 4.1 Command set tree for LTU, 1xDSL, 1xE1, 1xEth devices.

User Manual




Figure 4.2 Command set tree for LTU, 1xDSL, NONExE1, NxEth devices.

User Manual




Figure 4.3 Command set tree for LTU, 1xDSL, NxE1, NxEth devices.

User Manual




Figure 4.4 Command set tree for LTU, NxDSL, NONExE1, NxEth devices.

User Manual




Figure 4.5 Command set tree for LTU, NxDSL, NxE1, NxEth devices.

User Manual




Figure 4.6 Command set tree for NTU, 1xDSL, 1xE1, 1xEth devices.

User Manual




Figure 4.7 Command set tree for NTU, 1xDSL, NONExE1, 1xEth devices.

User Manual




Figure 4.8 Command set tree for NTU, NxDSL, NONExE1, 1xEth devices.




Figure 4.9 Command set tree for NTU, NxDSL, NxE1, 1xEth devices.

4.2 ETHERLINK II software

Every ETHERLINK II device can contain up to two version of the software in EEPROM: unchangeable (standby) software (software No. 1) and upgradeable software (software No. 2). Two versions are necessary to prevent the device failure due to downloading of faulty or damaged software or due to hardware failure (for example, power cutoff, etc.) during downloading of the new software.

User Manual

During downloading, the new software overwrites the upgradeable software. If the new software downloading via X-modem is successful, a message appears that the modem should be restarted to start operating under the new software. After the restart, i.e., when the new version of the upgraded software is started for the first time, the operator should confirm the downloaded software. After confirmation, this software becomes unchangeable. If downloading was interrupted or there was a failure in the data transmission, a message is displayed. In this case, if the data has already been partially downloaded into the modem and the upgradeable software is damaged, the unchangeable software will be used to start the modem (repeat the downloading of the software).

By default, the upgradeable software is the basic one, if it was confirmed. If the upgradeable software was not confirmed after the first start or it was damaged (invalid data format, incorrect checksum), the standby software is downloaded.

The ways of software downloading are presented in detail in Part 3 of the present document.

4.3 Configuration storage and application

On the whole the system stores four configurations: running configuration, startup configuration, new configuration and backup configuration.

The *running configuration* contains all configuration values used to configure the device current operation. Two modems, having the same version of the software and the same running configurations, should operate similarly. The running configuration is stored in the device RAM. The current parameters determine operation of the device till the next restart of the device or actions on the running configuration (storage and etc.). During initialization the initial parameters of the running configuration are dubbed from the startup configuration.

The *startup configuration* contains all configuration values which will be used to configure the device after its restart. The startup configuration is stored in EEPROM and is used to initialize the running configuration during the system start-up.

The *new configuration* stores changes in configuration parameters combined into groups of parameters requiring confirmation of changes (i.e., this configuration stores setting, which should be confirmed after being changed, for example, IP-address of the device). The new configuration is stored in the device RAM. After setting all necessary changes from the group, the system administrator confirms changes in the group, and values belonging to this group are written from the new configuration into the running one. In this case, the simultaneous application of all setting in the group is provided.

The *backup configuration* is a backup of the current configuration. The backup configuration is stored in the EEPROM. During the configuration restoration, values from the backup configuration are copied to the startup configuration.

All configuration parameters are divided into three groups according to their application:

- configuration parameters applied after the restart;
- configuration parameters applied instantly;
- configuration parameters requiring confirmation.

Configuration changes, which are used after the restart, are written into the startup configuration, but before the restart the device continues functioning according to its "old" configurations. During the device restart, the values of these configurations are copied from the startup configuration into the running one and thus become valid (see Figure 4.10).

Figure 4.10 Operations with configuration parameters with application after the restart.

Configuration changes, which are used instantly, are written into the running, startup and new configurations, and the device continues functioning according to these configurations (see Figure 4.11).

Figure 4.11 Operations with the configuration parameters with the instant application.

Changes in configurations, which are part of a group of configurations requiring confirmations, are initially written into the new configuration. After the administrator confirms changes in the group of configurations, this group is copied from the new configuration into the running configuration and the device starts functioning according to these configurations. The administrator also can confirm changes in all groups. After the received running configuration is checked, the administrator can confirm this configuration in this case changes in all groups are copied from the running configuration into the startup configuration (see Figure 4.12).

Figure 4.12 Operations with configuration parameters that should be confirmed.

4.4 Groups of commands requiring confirmation

The following four groups of parameters require confirmation in ETHERLINK II devices: LINE, NET, VLAN and SNMP. Configurations of each group change by using special commands (see Fig. 2.13). The APPLY <name of the group> command is used to apply changes in configurations performed in a group. After this, the unit applies changes in configurations. If groups LINE, NET, VLAN were changed not in the local management session via the RS-232 interface of the shelf but via TELNET the management session breaks and the unit waits for the second connection within 5 minutes (for the LINE group – 30 minutes). If the LINE group was changed remotely (using the CONNECT command), the unit waits for the second connection within 30 minutes. If within this time the operator did not enter the modem menu, the changed parameters are read from the startup configuration of the unit. Therefore, it is possible to restore the configurations of the unit.

A “successful” configuration can become the startup configuration by using the CONFIRM command.

The groups of commands requiring confirmation are listed below.




Figure 4.13 Groups of commands requiring confirmation.

4.5 Command syntax

The following rules are used to describe commands:

- parameters in angular brackets < > are obligatory;
- parameters in direct brackets [] are not obligatory;
- the symbol (/) between parameters requires to enter one of the listed parameters;
- in real commands brackets and the vertical line are not entered, they are used for description;
- after the command is typed, press <enter>.

4.6 Commands

4.6.1 Main Menu

4.6.1.1 View of the main menu

The main menu is presented below:

```

MODEL SA-PAM-SAN-E1B/Ethernet
HW 1.4
SW 1.1.4
DATE 29-4-2005
ID
RUNS 0d 00:01:39
ALARM URGENT
STATUS LINK UP
MODEL_DESC Standalone xDSL/E1/Ethernet 120 Ohm
IP 10.0.8.151

```

Copyright (C) 2005 by S-Access

```

----- Main Menu -----
1. Performance management (PM)
2. Fault and maintenance management (FMM)
3. Configuration management (CM)

5. Exit
-----
Select [1..5]
CO_MM>

```

To select the desired sub-menu, type the appropriate number from “1” to “5” and press<enter>.

4.6.1.2 System invitation

The following format of the system invitation is used in all menus:

<cc>_<addr>_<sf>>, where **cc** is the device mode [RR – regenerator, CO – Master; CP – Slave; CX – a modem with both types of interfaces, CA – a device with the automatic selection of the DSL line parameters (<MASTER>, <BASERATE>, <PAM> and <ANNEX>)];

addr is the address of the regenerator in the system (only for regenerators), or a device in the shelf (only for Subrack devices);

sf is the short form of the current menu (MM – Main Menu; PM – Performance Management; FMM – Fault and Maintenance Management; CM – Configuration Management).

For example:

CO_PM> - the device is in the Master mode (the Performance Management menu).

4.6.2 Performance management menu

After typing “1” in the main menu and pressing<enter>, the following message is displayed:

```

Performance management activated
Enter <M> to return to MAIN, or <H> for HELP information

```

4.6.2.1 <H> command

Type <H> and the monitor lists all available commands in the performance sub-menu:

```

Performance management activated

```

User Manual

Enter <M> to return to MAIN, or <H> for HELP information

```
CO_PM>
-----
Type 'H <command>' to get additional help on <command>
TCPIP                Show TCP/IP statistics
TCPIP C              Show TCP/IP statistics continuously
ICMP                 Show ICMP statistics
ICMP C               Show ICMP statistics continuously
MAC                  Show MAC Rx/Tx statistics
MAC C                Show MAC Rx/Tx statistics continuously
G826                 Display xDSL G.826 statistics
G826 C               Display xDSL G.826 statistics continuously
G826 E1              Display E1 G.826 statistics
G826 E1 C            Display E1 G.826 statistics continuously
RESETG826            Reset G.826 statistics
NETSTAT              Show network interfaces statistics
RESETNSTAT            Reset network interfaces statistics
CONNECT [1:13,R]     Establish connection to remote unit
M                    Return to Main Menu
H                    Show available commands
-----
CO_PM>
```

For the regenerators, the list of available commands is as follows:

```
RR_01_PM>H
-----
Type 'H <command>' to get additional help on <command>
TCPIP                Show TCP/IP statistics
TCPIP C              Show TCP/IP statistics continuously
ICMP                 Show ICMP statistics
ICMP C               Show ICMP statistics continuously
MAC                  Show MAC Rx/Tx statistics
MAC C                Show MAC Rx/Tx statistics continuously
G826                 Display xDSL G.826 statistics
G826 C               Display xDSL G.826 statistics continuously
RESETG826            Reset G.826 statistics
NETSTAT              Show network interfaces statistics
RESETNSTAT            Reset network interfaces statistics
CONNECT [1:13,R]     Establish connection to remote unit
M                    Return to Main Menu
H                    Show available commands
-----
RR_01_PM>
```

4.6.2.2 <TCPIP> command

The <TCPIP> command displays a summary table of statistics of ICMP, IP and TCP protocols, i.e., packets processed by the internal INT interface.

```
CO_09_PM>TCPIP
-- TCP/IP Statistics ---- ICMP ----- IP -- IP Frag ----- TCP -----
Transmitted packets:      4           631           0           376
Retransmitted packets:    0           0           0           0
Received packets:         4          1160           0          625
Forwarded packets:        0           0           0           0
Dropped packets:          0           0           0           0
Checksum error:           0           0           0           0
Invalid length error:     0           0           0           0
Out of memory error:      0           0           0           0
Routing error:            0           0           0           0
Protocol error:           0           0           0           0
Error in options:         0           0           0           0
Misc error:               0           0           0           0
-----
CO_09_PM>
```

User Manual

The column ICMP shows the ICMP operation, the column IP shows statistics of the IP protocol, the column IP frag displays the operation with fragmented IP packets and the column TCP displays the statistics of the TCP protocol.

Transmitted packets – the number of transmitted packets.

Retransmitted packets – the number of retransmitted packets. Not applied to IP and IP Frag.

Received packets – the number of received packets.

Forwarded packets – the number of forwarded packets. Not applied to TCP.

Dropped packets – the number of dropped packets.

Checksum error – the number of packets with the checksum error.

Invalid length error – the number of packets with an invalid length error.

Out of memory error – the number of packets out of memory of the device TCP/IP stack.

Routing error – the number of routing errors when transmitting packets.

Protocol error – the number of packets with protocol errors and with limitations imposed by the protocol.

Error in options – the number of IP packets with the invalid field “options”.

Misc error – the number of other errors.

Option: C – update the table continuously.

Note: The system does not calculate statistics over all ICMP packets passing through network interfaces of the modem. Calculation is performed only over packets forwarded to the internal network interface of the modem: broadcast and multicast packets, and packets used in telnet, SNMP, WEB.

4.6.2.3 <MAC> command

The <MAC> command displays the table of the Ethernet interface statistics of the modem.

```
CO_PM>MAC
----- LAN interface --- ETH1 --- ETH2 --- ETH3 --- ETH4 -
Tx bytes          :          899M          64k          0          17M          0
Tx packets        :          1400k          112          0          25k          0
Tx packets good   :          24k          112          0          25k          0
Tx PAUSE frames   :          0          0          0          0          0
Tx errors         :          0          0          0          0          0
Tx excess. collisions:          0          0          0          0          0
Tx late collisions :          0          0          0          0          0
Tx deferred       :          0          0          0          0          0

Rx bytes          :          16M          1411k          0          900M          0
Rx packets        :          24k          956          0          1401k          0
Rx packets good   :          24k          956          0          1401k          0
Rx MAC control frames:          0          0          0          0          0
Rx errors         :          0          0          0          0          0
Rx alignment errors :          0          0          0          0          0
Rx CRC errors     :          0          0          0          0          0
Rx frames too long :          0          0          0          0          0

Available time    :          9221          9232          0          9221          0
Unavailable time  :          11          0          9232          11          9232
-----
CO_PM>
```


User Manual

Option: C – update the table continuously.

Tx/Rx bytes – the number of bytes in successfully transmitted/received packets.

Tx/Rx packets – the number of transmitted/received Ethernet packets (including errored packets).

Tx/Rx packets good – the number of successfully transmitted/received Ethernet packets.

Tx PAUSE frames – the number of transmitted PAUSE packets.

Rx MAC control frames – the number of received MAC control frames by the Ethernet connection.

Tx/Rx errors – the number of transmitted/received errored Ethernet packets.

Tx excess. collisions (Tx excessive collision) – the number of packets not transmitted due to 16 or more collisions during transmission.

Tx late collision – the number of late collisions.

Tx deferred – the number of deferred packets due to delays in transmission.

Rx alignment errors – the number of Ethernet frames with a number of bits indivisible by 8.

Rx CRC Error – the number of Ethernet frames containing CRC errors.

Rx frames too long – the number of received frames exceeding the maximum length.

Available time – the period when measurements of the parameters are possible (i.e., the number of seconds in the measurement period when the communication was established).

Unavailable time – the period when the measurements of the parameters are impossible (i.e., the number of seconds in the measurement period when the communication was not established).

In the table, ETH1 – ETH4 correspond to physical ports on the front panel of the device, the LAN interface corresponds to the internal network port of the device (LAN port). The devices with one physical Ethernet port display in the table only the LAN port.

Note: The <MAC> command shows statistics of packets passed through the real physical Ethernet interface. The statistics of Ethernet packet transmitted over other network interfaces is displayed using the <NETSTAT> command.

4.6.2.4 <G826 E1> command

The <G826 E1> command displays the ITU-T G.826 error performance parameters on the E1 side.

If the CRC4 mode is on for both channels, the following parameters are displayed:

```
CO_PM>G826 E1
~~~~~
G.826 Error Performance : 1-CRC4 1-E-Bit
~~~~~
Errored blocks          : 00000000 00000000
Errored seconds         : 00000000 00000000
Severely errored seconds : 00000000 00000000
Background block errors : 00000000 00000000
ESR [%]                 : 0.00 0.00
SESR [%]                : 0.00 0.00
BBER [%]                : 0.00 0.00
Available time          : 00000145 00000145
Unavailable time        : 00000000 00000000
~~~~~
CO_PM>
```

If the CRC4 mode is off for the E1 interface, the following parameters are displayed:

```
CO_PM>G826 E1
~~~~~
G.826 Error Performance : 1-FAS
~~~~~
```

User Manual

```

Errored blocks          : 00000000
Errored seconds         : 00000000
Severely errored seconds : 00000000
Background block errors : 00000000
ESR [%]                 : 0.00
SESR [%]                : 0.00
BBER [%]                : 0.00
Available time          : 00002341
Unavailable time        : 00000000
~~~~~
CO_PM>

```

If the ITU-T G.704 framed mode is off, the following parameters are displayed:

```

CO_PM>G826 E1
~~~~~
G.826 Error Performance : 1
~~~~~
Errored blocks          :
Errored seconds         :
Severely errored seconds :
Background block errors :
ESR [%]                 :
SESR [%]                :
BBER [%]                :
Available time          : 00002341
Unavailable time        : 00000000
~~~~~
CO_PM>

```

Option: C – update the table continuously.

Digits 1, 2, 3 and 4 in the first row of the table show parameters for the first, second, third and fourth E1 interfaces, respectively.

Definitions:

CRC4: Cyclic redundancy check indicating errored submultiframes received on the E1 side;

E-bit: CRC4-indication bit denoting received errored submultiframes received on the E1 side;

FAS: Errored frame alignment signal received on the E1 side;

Errored Block (EB): a block in which one or more bits are in error;

Errored Second (ES): A one second period with one or more errored blocks or at least one defect;

Severely Errored Second (SES): a one-second period, which contains more than 805 errored blocks per second (if CRC4 options are enabled) or the number of errored framed alignment is more than 28 per second. SES is a subset of ES;

Background Block Error (BBE): an errored block not occurring as a part of SES.

Errored Second Ratio (ESR): the ratio of ES to total seconds in available time during a fixed measurement interval;

Severely Errored Seconds Ratio (SESR): the ratio of SES to the total number of error-free seconds in available time during a fixed measurement interval;

Background Block Error ratio (BBER): the ratio of BBE to the total number of error-free seconds in available time during a fixed measurement interval;

Available time: the period when measurements of the parameters are possible;

Unavailable time: the period when the measurements of the parameters are impossible.

4.6.2.5 <RESETG826> command

The <RESETG826> command clears the ITU-T G.826 error performance parameter counters.

4.6.2.6 <G826> command

The <G826> command displays the ITU-T G.826 performance parameters of the line.

User Manual

Depending on the number of DSL channels in the system, a table is displayed containing 1, 2 or 4 columns of data.

```
CO_PM>G826
```

```
-----
G.826 Error Performance : CRC6 1
-----
```

```
Errored blocks      : 00000000
Errored seconds     : 00000000
Severely errored seconds : 00000000
Background block errors : 00000000
ESR [%]            : 0.00
SESR [%]           : 0.00
BBER [%]           : 0.00
Available time      : 00000123
Unavailable time     : 00000012
-----
```

```
CO_PM>
```

Option: C – update the table continuously.

Definitions:

CRC6: Cyclic redundancy check indicating errored blocks received on the xDSL side;

Errored Block (EB): a block in which one or more bits are in error. The transmission duration of one block is 6 ms;

Errored Second (ES): A one second period with one or more errored blocks or at least one defect;

Severely Errored Second (SES): a one-second period, which contains more than 30% of errored blocks per second from the total number of all blocks received. SES is a subset of ES;

Background Block Error (BBE): an errored block not occurring as a part of SES.

Errored Second Ratio (ESR): the ratio of ES to total seconds in available time during a fixed measurement interval;

Severely Errored Seconds Ratio (SESR): the ratio of SES to the total number of error-free seconds in available time during a fixed measurement interval;

Background Block Error ratio (BBER): the ratio of BBE to the total number of error-free seconds in available time during a fixed measurement interval;

Available time: the period when measurements of the parameters are possible;

Unavailable time: the period when the measurements of the parameters are impossible.

4.6.2.7 <NETSTAT> command

The <NETSTAT> command displays statistics of LAN (Ethernet), WAN1 – WAN4 and INT (internal management port) interfaces.

```
CO_PM>STATS LAN
```

```
~~~~~
Statistics      : LAN      WAN1      WAN2      Int
~~~~~
Bytes sent       : 120      1230      1680      120
Packets sent     : 5        10       10        2
HP packets sent  :          5        6
LP packets sent  :          5        4
HP queue overloads : 0        0        0
LP queue overloads : 0        0        0
Transmitting errors : 1        1        1
Bytes received   : 2310     110      110       110
Packets received : 20        2        2        2
Test packets rcvd :          0        0
Receiving errors : 0        0        0
Available time   : 101
Unavailable time  : 11
~~~~~
```

```
CO_PM>
```

User Manual

LAN – Ethernet port.

WAN1 – WAN4 – WAN1, WAN2, WAN3 and WAN4 ports, respectively.

Int – internal port of management and monitoring (telnet, web, snmp, ping).

Bytes sent – the number of transmitted bytes.

Packets sent – the number of transmitted packets.

HP packets sent – the number of transmitted high priority packets.

HP queue overloads – the number of overloads in the queue of high-priority packets.

LP packets sent – the number of transmitted low-priority packets.

LP queue overloads – the number of overloads in the queue of low-priority packets.

Transmitting errors – the number of transmitting errors. The possible reasons of transmitting errors: 1) Excessive collisions error; 2) Excessive deferral error; 3) Transmit FIFO underrun.

Bytes received – the number of received bytes.

Packets received – the number of received packets.

Test packets rcvd (received) – the number of received test packets.

Receiving errors – the number of receiving errors. Possible reasons of receiving errors: 1) Frame Alignment Error; 2) CRC Error; 3) Receive FIFO overrun.

Available time – the period when measurements of the parameters are possible;

Unavailable time – the period when the measurements of the parameters are impossible.

4.6.2.8 <RESETNETSTAT> command

The <RESETNETSTAT> command clears counters used to display statistics on data transmission via interfaces.

4.6.2.9 <ALLG826 [N=1..4]> command

The <ALLG826 [N=1..4]> command displays the G.826 performance statistics in the line for the local device, for the remote device and for regenerators.

The statistics is displayed for the N xDSL connection. In single-channel systems this parameter can be absent.

Depending on the number of regenerators (0 – 13), the table is compiled of 1, 2 or 3 blocks with 1 – 6 columns of data. Taking into account that each block of the table requires a considerable number of screen lines, press any key to display the rest of the table.

CO_01_PM>ALLG826

G.826 Performance :	HTU-C	RR 1	RR 2	RR 3	RR 4	RR 5

Errored blocks	: 00000000	00000000	00000000	00000000	00000000	00000000
Errored seconds	: 00000000	00000000	00000000	00000000	00000000	00000000
SES	: 00000000	00000000	00000000	00000000	00000000	00000000
BBE	: 00000000	00000000	00000000	00000000	00000000	00000000
ESR [%]	: 0.00	0.00	0.00	0.00	0.00	0.00
SESR [%]	: 0.00	0.00	0.00	0.00	0.00	0.00
BBER [%]	: 0.00	0.00	0.00	0.00	0.00	0.00
Available time	: 00000123	00000123	00000123	00000123	00000123	00000123
Unavailable time	: 00000012	00000012	00000012	00000012	00000012	00000012

Press any key to continue...						

G.826 Performance :	RR 6	RR 7	RR 8	RR 9	RR 10	HTU-R

Errored blocks	: 00000000	00000000	00000000	00000000	00000000	00000000

User Manual

```

Errored seconds      : 00000000 00000000 00000000 00000000 00000000 00000000
SES                  : 00000000 00000000 00000000 00000000 00000000 00000000
BBE                  : 00000000 00000000 00000000 00000000 00000000 00000000

ESR [%]              :      0.00      0.00      0.00      0.00      0.00      0.00
SESR [%]             :      0.00      0.00      0.00      0.00      0.00      0.00
BBER [%]             :      0.00      0.00      0.00      0.00      0.00      0.00
Available time       : 00000123 00000123 00000123 00000123 00000123 00000123
Unavailable time     : 00000012 00000012 00000012 00000012 00000012 00000012
-----
CO_01_PM>

```

Definitions:

Errored Block (EB): a block in which one or more bits are in error. The transmission duration of one block is 6 ms;

Errored Second (ES): A one second period with one or more errored blocks or at least one defect;

Severely Errored Second (SES): a one-second period, which contains more than 30% of errored blocks per second from the total number of all blocks received. SES is a subset of ES;

Background Block Error (BBE): an errored block not occurring as a part of SES.

Errored Second Ratio (ESR): the ratio of ES to total seconds in available time during a fixed measurement interval;

Severely Errored Seconds Ratio (SESR): the ratio of SES to the total number of error-free seconds in available time during a fixed measurement interval;

Background Block Error ratio (BBER): the ratio of BBE to the total number of error-free seconds in available time during a fixed measurement interval;

Available time: the period when measurements of the parameters are possible;

Unavailable time: the period when the measurements of the parameters are impossible.

4.6.2.10 <RESETALLG826 [N=1..4]> command

The <RESETALLG826 [N=1..4]> command clears all the counters of the G.826 performance statistics for the Nth xDSL interface of the local device and regenerators connected to it and the remote device.

In single-channel systems the parameter N can be absent.

4.6.2.11 <CONNECT N:1..13/R> command

The <CONNECT N:1..13/R> commands initializes the management of the remote device.

The parameter N sets the number of the xDSL channel, over which the connection is initialized.

In single-channel systems the parameter N can be absent.

Notes:

1. The <CONNECT R> command in the Slave mode is only available if the Master device can be configured locally at this instant.
2. The <CONNECT N> (N=1..13) command initializes the management of the remote regenerator. The <CONNECT N> command is available only in the Master mode.
3. This command is not provisioned for regenerators.
4. If the channel of remote management is blocked (for example, a message or a table are not displayed completely), press Enter.

4.6.2.12 <M> command

After the <M> command is entered the device displays the main menu.

User Manual

4.6.3 Fault and maintenance management menu

After typing "2" in the main menu and pressing enter, the following message is displayed:

```
Fault and maintenance management activated
Enter <M> to return to MAIN, or <H> for HELP information
```

4.6.3.1 <H> command

Type <H> and the monitor lists all available commands in the fault and maintenance sub-menu:
For Stand Alone devices, the following information is displayed:

```
CO_FMM>
-----
Type 'H <command>' to get additional help on <command>
NM                               Trace xDSL noise margin
STATUS                           Show current work parameters DSL line
STATUS ETH                       Show Ethernet status
MACTABLE                         Print MAC table
MACTABLE C                       Clear MAC table
LOOP2 [1:13,R] [ON/OFF]         Starts/stops the remote loopback at the xDSL interface
ALARM                            Display alarms
ALARM T                          Display alarms continuously
LOOP1 [ON/OFF]                  Start/stop local loopback at the E1 interface
ACO                              Show alarm cutoff configuration
ACO [GROUP] [ON/OFF]            Change alarm indication for alarm group GROUP
STARTAL                          Toggles the analog loopback on and off
RESTART                          Restart xDSL channel
RESET                            Reset modem
SOFTUPDATE                       Update software
SOFTCONFIRM                      Confirm uploaded software
SOFTINFO                         List loaded software
APPLY [ALL/GROUP]               Apply changes to running configuration
CONFIRM                         Confirm running configuration
BACKUP                           Backup running configuration
RESTORE                          Restore startup configuration from backup
DIFF [N/R/S/B] [N/R/S/B]        Show differences between configurations
DUMP [N/R/S/B]                  Dump selected configuration
LOAD                             Load configuration via XModem
POWERMODE [0..5]                Set device power consumption mode
CONNECT [1:13,R]                Establish connection to remote unit
M                                Return to Main Menu
H                                Show available commands
-----
```

```
CO_FMM>
```

For regenerators, the following information is displayed:

```
RR_FMM>H
-----
Type 'H [command]' to get additional help on [command]
NM                               Trace xDSL noise margin
STATUS                           Show current work parameters DSL line
ALARM                            Display alarms
ALARM T                          Display alarms continuously
ACO                              Show alarm cutoff configuration
ACO [GROUP] [ON/OFF]            Change alarm indication for alarm group GROUP
STARTAL [N]                     Toggles Nth xDSL channel the analog loopback on and off
RESTART [N]                     Restart Nth xDSL channel
RESET                            Reset modem
SOFTUPDATE                       Update software
SOFTCONFIRM                      Confirm uploaded software
SOFTINFO                         List loaded software
APPLY [ALL/GROUP]               Apply changes to running configuration
CONFIRM                         Confirm running configuration
BACKUP                           Backup running configuration
RESTORE                          Restore startup configuration from backup
DIFF [N/R/S/B] [N/R/S/B]        Show differences between configurations
```

User Manual

```

DUMP [N/R/S/B]      Dump selected configuration
LOAD                Load configuration via XModem
POWERMODE [0..5]    Set device power consumption mode
M                  Return to Main Menu
H                  Show available commands

```

```
-----
RR_FMM>
```

4.6.3.2 <NM> command

The <NM> command displays the ITU-T G.991.2 Noise Margin performance parameters.
(The maximum possible increase in the noise margin at which the BER is expected to be less than 10^{-7} .)

The action of the <NM> command terminates by entering any other command or by pressing "enter".

```

CO_FMM>NM
Channel:  DSL1      DSL2      DSL3      DSL4
xDSL NM:   10.5     11.5     10.5     10.0 dB
xDSL NM:   10.5     11.5     10.5     10.0 dB
xDSL NM:   10.5     11.5     10.5     10.0 dB

```

```
↓
```

```
CO_FMM>
```

The number of columns is equal to the number of xDSL channels of the device.
Normal quality of data transmission is possible only for $NM \geq 8$ dB.

4.6.3.3 STATUS> command

The <STATUS> command displays the actual status of the xDSL transceiver.

```
CO_04_FMM>STATUS
```

```

-----
Status      :      DSL1      DSL2      DSL3      DSL4
-----
I/F mode    :      CP        CO        CP        CO
SYNC        :      1         1         1         1
SEGD        :      1         1         1         1
Power backoff :      0.0      0.0      0.0      0.0 dbm
Far end power backoff :      1.0      1.0      1.0      1.0 dbm
Loop attenuation :      14.0     14.0     14.0     14.0 dB
NMR         :      11.5     11.5     11.5     11.5 dB
Bitrate     :      4104     4104     4104     4104 kbit/s
SRU #       :      0         0         0         0
Active sync. source :      E1-1     E1-2     E1-3     E1-4
-----
Temperature :      37.375 C
-----

```

```
CO_04_FMM>
```

For regenerators, the parameters are displayed for two DSL channels.

Table 4.2 «<STATUS> - definitions».

Parameter	Value	Description
I/F mode	CO	The interface is in the Master mode
	CP	The interface is in the Slave mode
SYNC	1	Synchronization in the xDSL line is established.
	- (0)	Synchronization in the xDSL line is absent.

User Manual

SEGD	1 0 -	Data, transmitted over the xDSL line, are valid Data, transmitted over the xDSL line, are not valid Data are not received
Power backoff	<i>N</i>	Output signal power [dBm]
Far end power backoff	<i>N</i>	Receiver gain [dBm] (in the current version invalid values are displayed)
Loop attn	<i>N</i>	Attenuation in the loop [dB]
NMR	<i>N</i>	Maximum possible increase in the noise margin for which the BER is expected to be no less than 10^{-7} [dB]
Bitrate	<i>N</i>	Data transmission rate in the xDSL line [kbit/s]
SRU	<i>N</i>	Number of regenerators in the system
Active sync. source	<i>External</i> <i>E1-1</i> <i>E1-2</i> <i>E1-3</i> <i>E1-4</i> <i>Internal</i>	Active sync source External sync E1-1 network interface E1-2 network interface E1-3 network interface E1-4 network interface Internal sync source
Temperature	<i>N</i>	Unit temperature [C°] (only for Sub Rack devices)
Power mode	P0 P1 P2 P3 P4 P5	CPU clock frequency is 50MHz. CPU clock frequency is 50MHz smart start CPU clock frequency is 25MHz smart start CPU clock frequency is 10MHz smart start CPU clock frequency is 5.5MHz smart start CPU clock frequency is 5.5MHz smart start

4.6.3.4 <STATUS ETH> command

The <STATUS> command displays parameters of the Ethernet port (ETH1 – ETH4), namely the rate and the operation mode:

```
CO_09_FMM>STATUS ETH
Ethernet port 1 speed/duplex: 100 FULL
Ethernet port 2 speed/duplex: 10 FULL
Ethernet port 3 speed/duplex: 10 HALF
Ethernet port 4 speed/duplex: ---
CO_09_FMM>
```

4.6.3.5 <MACTABLE> command

The <MACTABLE> displays the dynamic table of MAC addresses:

```
CO_FMM>MACTABLE
I/F  VID      MAC              I/F  VID      MAC
LAN  1      00:0c:6e:ea:ee:4a  LAN  1      00:c0:26:a3:6e:a2
LAN  1      00:c0:26:31:66:3e  LAN  1      00:0c:f1:6e:19:8c
LAN  1      00:0f:24:b5:65:d0  LAN  1      00:1f:00:00:01:eb
LAN  1      02:01:00:00:00:00  LAN  1      00:c0:df:0e:b5:40
LAN  1      00:80:48:15:72:0b  LAN  1      00:05:5d:c7:e6:8f
LAN  1      00:c0:26:a3:65:32  LAN  1      00:c0:26:a7:cd:13
LAN  1      00:c0:26:31:5d:61  LAN  1      00:80:48:15:d3:06
LAN  1      00:c0:26:31:65:07  LAN  1      00:08:0d:b1:e9:fa
LAN  1      00:c0:26:a6:d2:25  LAN  1      00:c0:26:a9:b2:0a
LAN  1      00:0d:61:b0:9d:57  LAN  1      00:0d:88:4f:b5:0e
LAN  1      00:0b:6a:f2:2f:93  LAN  1      00:c0:26:2c:fb:2b
INT  1      00:19:45:df:33:ae  LAN  1      00:0a:48:07:86:a2
LAN  1      00:a0:c9:42:17:0e  LAN  1      00:30:48:10:7f:46
LAN  1      00:60:52:0b:fd:97
CO_FMM>
```

Option: C – update the table continuously.

Definitions:

I/F – the name of the port from which an Ethernet packet was transmitted to the internal switch.

VID – VLAN ID (VLAN number) transmitted to the internal switch of the Ethernet packet.

MAC – MAC address of the sender of the Ethernet packet.

The size of the dynamic table of MAC addresses is 32768 cells. The MAC address table automatically deletes old records after a certain data aging time. In case there are not enough cells in the table, the aging time decreases and the stale data are deleted faster. The procedure can be repeated many times. Therefore, the table overflow does not occur even in networks incorporating thousands of devices.

4.6.3.6 <ALARM> command

The <ALARM> command displays the actual alarm status of the local device:

For systems with different numbers of E and xDSL channels, the number of columns displayed is also different, though the table structure remained unchanged.

For single-channel devices, the alarm table is displayed in the following way:

```
CP_FMM>ALARM
```

```
-----
Alarm status : E1-1                                xDSL : DSL1
-----
LOS-S        : on                                  LOS  : off
LFA-S        : on                                  LOSW : off
AIS-S        : off                                 SEGD : off
AIS-R        : off                                 BER-H : off
LOOP1        : off                                 ALB  : off
BER-S        : off                                 SEGA : off
```

User Manual

```

                                LOOP2 :   off
-----
Ethernet                               Maintenance
-----
LOS-E          : off                HW-F   : off
                                DSL-F   : off
-----

CP_FMM>
For regenerators, the alarm table is displayed in the following way:
RR_01_FMM>ALARM
-----
Alarm status :  DSL1  DSL2
-----
LOS           :   off   on
LOSW          :   off   on
SEGD          :   off   off
BER-H         :   off   off
ALB           :   off   off
SEGA          :   off   off
LOOP2         :   off   off
-----

Ethernet                               Maintenance
-----
LOS-E          : off                HW-F   : off
                                DSL-F   : off
-----

RR_01_FMM>

```

Table 4.3 «<ALARM> - definitions».

<i>Definitions (E1-1, E1-2):</i>	
LOS-S	Loss of signal on the E1 side
LFA-S	Loss of frame alignment on the E1 side
AIS-S	Receiving AIS on the E1 side
AIS-R	Receiving AIS on the E1 side by a remote device
BER-S	The block error rate on the E1 side exceeded the admissible value
LOOP1	A loop is activated on the network interface in the direction of the E1 equipment
<i>Definitions (Ethernet):</i>	
LOS-E	Loss of signal on the Ethernet interface
<i>Definitions (xDSL):</i>	
LOS	Loss of signal in xDSL
LOSW	Loss of signal or frame alignment in xDSL (loss wire)
SEGD	A failure in the line (segment degradation)
BER-H	The block error rate in the line is according to G.826 $\geq 30\%$
LOOP2	A loop is activated on the line interface of a remote device in the direction of the local device
SEGA	Errored data or errored frame alignment (segment alarm)
ALB	Analog loopback is active

<i>Definitions (Maintenance):</i>	
HW-F	Hardware failure
S1-F	Line card failure
ROCNF	Configuration of the remote device is not compatible with the configuration of the local device (for example, the local device is configured to transmit Ethernet data, while the remote device is configured to transmit two E1 streams)

Option: T – enable the continuous updating of the table of actual alarm statuses.

4.6.3.7 <LOOP1 ON/OFF [N=1..4]> command

The <LOOP1 ON/OFF [N=1..4]> command activates/deactivates the local loopback on the network interface (E1 interface).

```
CO_FMM>LOOP1 ON
Local loopback on E1-1 interface has been set
CO_FMM>LOOP1 OFF
Local loopback on E1-1 interface has been cleared
CO_FMM>
```

4.6.3.8 <LOOP2 N:ADDR ON/OFF> command

The <LOOP2 N:ADDR ON/OFF> command activates/deactivates the remote loopback on the line interface.

The parameter N:ADDR sets the number N of the DSL interface and the device address (as in the CONNECT command). In single-channel systems, the parameter N is not obligatory.

The command <LOOP2> with parameters N=1..13 activates the loopback on the regenerator, whose number is specified by the value of N. The regenerators are numbered starting from the modem.

The command <LOOP2> with the parameter N=R activated the remote loopback on the remote modem.

```
CO_FMM>LOOP2 R ON
LOOP2 activated
CO_FMM>LOOP2 R OFF
LOOP2 deactivated
```

4.6.3.9 <STARTAL ON/OFF N> command

The <STARTAL ON/OFF N> command starts the analog loopback at the line interface of the device with the number N (<STARTAL ON 1> starts the analog loopback at the DSL1 interface).

The <STARTAL OFF N> stops this loopback.

For single-channel modems, the <STARTAL> command is entered without the parameter N.

```
CO_FMM>STARTAL
Analog loopback started
CO_FMM>STARTAL
Analog loopback stopped
CO_FMM>
CO_09_FMM>STARTAL ON 1
Analog loopback started
CO_09_FMM>STARTAL OFF 1
Analog loopback stopped
CO_09_FMM>
```

Note: This command is used in the Master mode. Detach the cable from the xDSL connector before starting the analog loopback.

4.6.3.10 <RESTART [N=1..4]> command

The <RESTART [N=1..4]> command restarts the corresponding xDSL channel. The command first causes the loss of sync between modems which later restores. For single-channel devices the command is used without any additional parameters.

```
CP_FMM>RESTART
CP_FMM>
RR_FMM>RESTART 1
Restarting channel 1
RR_FMM>
```

4.6.3.11 <RESET> command

The <RESET> command restarts the device.

```
CP_FMM>RESET
```

4.6.3.12 <ACO [GROUP ON/OFF]> command

The <ACO> command without additional parameters lists deactivated alarm relays.

```
CO_FMM>ACO
E1-1, ETHERNET
CO_FMM>
```

The <ACO [GROUP ON/OFF]> command activated/deactivates the GROUP alarm relays. Available groups of alarm relays:

GROUP	Description
E1-1 or E11	1 st E1 channel
E1-2 or E12	2 nd E1 channel
E1-3 or E13	3 rd E1 channel
E1-4 or E14	4 th E1 channel
E1	All E1 channels
ETH1 or ETHERNET1	1 st Ethernet port
ETH2 or ETHERNET2	2 nd Ethernet port
ETH3 or ETHERNET3	3 rd Ethernet port
ETH4 or ETHERNET4	4 th Ethernet port
ETH or ETHERNET	All Ethernet ports
DSL1 or XDSL1	1 st DSL channel
DSL2 or XDSL2	2 nd DSL channel
DSL3 or XDSL3	3 rd DSL channel

User Manual

GROUP	Description
DSL4 or XDSL4	4 th DSL channel
DSL or XDSL	All DSL channels
RCONF	RCONF alarm

```
CO_01_FMM>ACO E1-1 OFF
ETHERNET
CO_FMM>
```

The deactivated alarm relay does not generate urgent or non-urgent alarms (i.e. does not affect the color of LEDs on the front panel and alarm relay statuses).

For generators, alarm relays DSL and Ethernet can be deactivated.

Note: By default in all configurations, the Ethernet alarm LED is blocked. By typing this command, the GROUP parameter can not contain several groups of alarm statuses.

For example: if it is necessary to deactivate alarm statuses of the group E1-1 and DSL, enter the ALCUTOFF command twice: first, with the parameter E1-1, and second, with the parameter DSL..

```
CP_FMM>ACO E1-1 ON
E1-1, ETHERNET
CP_FMM>ACO DSL ON
E1-1, xDSL, ETHERNET
CP_FMM>
```

4.6.3.13 <SOFTUPDATE> command

The <SOFTUPDATE> command downloads the new software into the modem by using the XMODEM or 1K XMODEM protocols. The SOFTUPDATE command downloads only the second version of the software into the flash memory. During the new software downloading the analysis of the % symbols is not performed.

```
CP_FMM>SOFTUPDATE
Flash manufacturer: Spansion
Flash device: S29AL016D(02)
Start address: 0x1000000
Flash size: 2048 KB
Now upload program via XModem or 1K XModem
CCC
```

After the new software is successfully downloaded, a message is displayed to restart the modem.

If the downloading failed, a message is displayed and the modem returns to the usual operation mode. (The operator can try again to download the software.) If the downloading was interrupted, the software is most likely damaged. The restart will result in this case in the downloading of the first version of the software.

4.6.3.14 <SOFTCONFIRM> command

The <SOFTCONFIRM> command confirms the new version of the software. After the new software is downloaded, a counter of the running software starts is switched on. If this software is not confirmed with the help of the <SOFTCONFIRM> command after the restart, it will not be valid after the next restart.

```
CO_FMM>SOFTCONFIRM
Software confirmed
CO_FMM>SOFTCONFIRM
Software already confirmed
```

CO_FMM>

4.6.3.15 <SOFTINFO> command

The <SOFTINFO> command displays information about copies of the software, which is stored in the device.

The device can contain two copies (different versions are possible) of the software. One of them is started after switching on, while the other is a backup software.

```
CP_FMM>SOFTINFO
1: ver.: 1.1.3, date: 2.6.2006, length: 328k, CRC OK, fixed
2: * ver.: 1.1.4, date: 3.7.2006, length: 330k, CRC OK, confirmed
CP_FMM>
```

The asterisk shows the running downloaded version.

ver – the number of the software version.

date – the date of the software creation.

length – the size in bytes.

CRC OK/FAIL – a label showing if the software is damaged or not.

The software status is displayed at the end of the corresponding line:

fixed – the software status: first, basic software cannot be downloaded from the console, does not require confirmation.

just loaded – the software status: downloaded second software.

not confirmed – the software status: non-confirmed second software.

confirmed – the software status: confirmed second software.

4.6.3.16 <APPLY ALL/NET/VLAN/LINE/SNMP> command

The <APPLY ALL/NET/VLAN/LINE/SNMP> command is used to apply changes in groups NET, VLAN or to apply changes in one of these groups.

As a result, changed in the group are written from the new configuration into the running one.

For example:

```
CO_FMM>APPLY VLAN
Applying configuration changes in group VLAN to running configuration
```

For example:

```
CO_FMM>APPLY ALL
Applying all configuration changes to running configuration
```

4.6.3.17 <CONFIRM> command

The <CONFIRM> command confirms the running configuration and writes it to the startup configuration.

As a result, after confirmation of changes in all groups of configuration variables, they will be written from the running configuration into the startup configuration.

For example:

```
CO_FMM>CONFIRM
Current running configuration is confirmed and written to
startup configuration in EEPROM
```

4.6.3.18 <BACKUP> command

The <BACKUP> command is used to create a backup of the running configuration of the device in the EEPROM.

As a result, the running configuration is written to the backup configuration.

For example:

User Manual

```
CO_FMM>BACKUP
Current running configuration is written to
backup configuration in EEPROM
CO_FMM>
```

4.6.3.19 <RESTORE> command

The <RESTORE> command restores the startup configuration from the backup configuration, which is written in the EEPROM.

As a result, values from the backup configuration are written into the startup configuration.

For example:

```
CO_FMM>RESTORE
Restored startup configuration from backup configuration.
Reset modem for all changes to take effect
CO_FMM>
```

The modem should be restarted in order the restored values become valid.

4.6.3.20 Viewing differences of configurations <DIFF N/R/S/B N/R/S/B > command

The <DIFF N/R/S/B N/R/S/B> command displays differences in configurations. The difference between four configurations is displayed: Running, New, Startup, or Backup (see Section 2.3).

For example:

```
CO_FMM>DIFF R B
-----
Running configuration      Backup configuration
-----
VLAN.VLANMASK.3
00 01                    | 00 07
-----
CO_FMM>
```

The command displays the name of the difference parameter and data from two configurations. In the above example one can see that the VLANMASK parameter of interface 3 (WAN2) of the VLAN group in the running configuration differs from the backup configuration.

If there are no differences, the result is presented as follows:

```
CO_FMM>DIFF N R
-----
New configuration        Running configuration
-----
--- No differences ---   --- No differences ---
-----
CO_FMM>
```

4.6.3.21 <DUMP N/R/S/B > command

The <DUMP N/R/S/B> command displays the dump of the corresponding configuration: Running, New, Startup or Backup. The text format used by the command can be also employed for reading or for the configuration downloading in the modem with the help of the `LOAD` command (see below).

For example:

```
CO_FMM>DUMP R
-----
Dump of running configuration
-----
NET.MAC ADDRESS
00 0F D9 00 10 03
M.DEVICE_ID
00 00 00 00 00 00 00 00 00 43 4F 4D 4D 4F 4E 00\
```

User Manual

```

00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00\
00
NET.MAC_SPEED
5A
SNMP.TRAPIP.0
00 00 00 00
SNMP.TRAPIP.1
00 00 00 00
SNMP.COMMUNITY
43 4F 4D 4D 4F 4E 00 20 60 00 00 13 00 02 B2 3C\
00 18 65 44 00 05 5E 2C FF FF FF FF 00 17 59 F8\
00
M.ALARM_CUTOFF
02
NET.IP
C0 A8 5A 14
NET.NETMASK
FF FF FF 00
NET.GATEWAY
C0 A8 5A 64
NET.PPPREMIP
C0 A8 5A 5A
PE1.G704.0
01
SE1.G704.1
01
PE1.CRC4DET.0
00
SE1.CRC4DET.1
00
...

```

CO_FMM>

The results of the command show the coded configuration of the device and can be copied from the terminal window into the notepad as well as saved on any data carrier. This txt file can be downloaded into a similar device with the help of the LOAD command via the XModem or 1K XModem protocols.

4.6.3.22 <LOAD> command

The <LOAD> command downloads the configuration file obtained with the help of the DUMP command into a device via the XModem or 1K XModem protocols.

For Windows 95 or above, this procedure can be performed with the help of the HyperTerminal program. By typing LOAD, the following text will be displayed in the terminal window:

```

CO_FMM>LOAD
Now upload configuration via XModem or 1K XModem
C

```

Select "Send File" in the Transfer menu. Select the protocol XModem or 1K XModem in the window which appears. Select the downloading configuration file and click the Send button.

If downloading is successful, a message will appear to reset the modem:

```

Configuration was loaded successfully.
For all configuration options to apply, type RESET to reset modem.
CO_FMM>

```

If the configuration file contained errors, a message with the number of the line in which the error was detected will be displayed. The configuration of the device in this case will not change.

4.6.3.23 <CONNECT N:1..13/R> command

The <CONNECT N:1..13/R> command initialized management of the remote device. See description of the <CONNECT> command in the Performance Management menu.

User Manual**4.6.4 Configuration Management menu**

After typing “3” in the main menu and pressing enter, the following message will be displayed:

```
Configuration management activated
Enter <M> to return to MAIN, or <H> for HELP information
```

The content of the configuration management menu mainly depends on the operation mode of the device. There are four possible modes of the device operation:

CO – all channels are in the Master mode, manual configuration.

CP – all channels are in the Slave mode, manual configuration.

CA – all channels are in the Slave mode, automatic configuration.

CX – a part of channels is in the Master mode, the rest channels are in the Slave mode, manual configuration.

In the CA mode, configuration of E1 and WAN streams is received from the line (from the CO device or regenerator), the configuration can be changed from the device in the CA mode. It is impossible to configure the channel reservation, to arbitrarily assign E1 streams to DSL channels and to arbitrarily set clock sources in the CA mode. Nevertheless, this mode satisfies 90% of users, because it does not require much effort to configure the device.

In the CA mode, the configurations received from the line are displayed by using the <CONFIG> command with the notation AUTO.

4.6.4.1 <H> command

Type <H> and the monitor lists all available commands in the configuration management sub-menu:

For Stand Alone devices:

```
CP_CM>H
-----
Type 'H [command]' to get additional help on [command]
CONFIG          Display local configuration
CONFIG [N/R/S/B] Display new/running/startup/backup configuration
MASTER [ON/OFF] Select DSL channel master/slave
BASERATE [N/AUTO] Set DSL channel baserate to Nx64k + 8k, N=[3..89]
PAM [16/32]      Set DSL channel line coding: PAM16, PAM32
PAYLOAD [list]   Set DSL channel payload
ANNEX [A,B,AB]   Set DSL channel Annex A or Annex B or Annex A/B
SETCLOCK [list]  Set DSL channel clock source priorities
G704 [ON/OFF]    Set E1 framer G704 mode
CRC4 [ON/OFF]    Set E1 framer CRC4 mode
AISDET [ON/OFF]  Set E1 framer AIS detection mode
AISGEN [ON/OFF]  Set E1 framer AIS generation mode
TS0GEN [ON/OFF]  Set E1 channel TS0 generation mode
DSLTS [list]     Select E1 channel timeslots, transmitted via DSL
WANTS [list]     Select E1 channel timeslots for WAN payload
PASSWORD [USER/ADMIN] Set user/administrator password
ID string        Set device ID
DEFAULT [0..3]   Set default configuration
DEFAULT EVERYTHING Set everything to default configuration
SERNUM           Show serial number
APPLY [ALL/GROUP] Apply changes to running configuration
CONNECT [1:13,R] Establish connection to remote unit
NET              Network configuration menu
M               Return to Main Menu
H               Show available commands
-----
CP_CM>
```

User Manual

For regenerators:

RR_CM>H

```

-----
Type 'H [command]' to get additional help on [command]
CONFIG                               Display local configuration
CONFIG [N/R/S/B]                   Display new/running/startup/backup configuration
MASTER [1/2/AUTO]                  Select master side or auto mode of DSL pair
BASERATE [N/AUTO]                  Set DSL channel baserate to Nx64k + 8k, N=[3..89]
PAM [16/32]                         Set DSL channel line coding: PAM16, PAM32
ANNEX [A,B,A/B]                   Set DSL channel Annex A or Annex B or Annex A/B
ID string                          Set device ID
DEFAULT [0..3]                     Set default configuration
DEFAULT EVERYTHING                 Set everything to default configuration
SERNUM                             Show serial number
APPLY [ALL/GROUP]                  Apply changes to running configuration
M                                  Return to Main Menu
H                                  Show available commands
-----

```

RR_CM>

For multi-channel modems:

CO_CM>H

```

-----
Type 'H [command]' to get additional help on [command]
AUTO [ON/OFF]                      Set CA mode
CONFIG                               Display local configuration
CONFIG [N/R/S/B]                   Display new/running/startup/backup configuration
MASTER [ON/OFF] [N]                Select Nth DSL channel master/slave
BASERATE [N/AUTO] [M]              Set Nth DSL channel baserate to Nx64k + 8k, N=[3..89]
PAM [16/32] [N]                    Set Nth DSL channel line coding: PAM16, PAM32
PAYLOAD [list] [N]                 Set Nth DSL channel payload
ANNEX [A,B,A/B] [N]                Set Nth DSL channel Annex A or Annex B or Annex A/B
SETCLOCK [list] [N]                Set Nth DSL channel clock source priorities
MULTIWIRE [N]                      Set N wire for multiwire, or 2+2
RESERVE [list1] {list2}            Set list1/list2 wires for first/second reserve group
G704 [ON/OFF] [N]                  Set Nth E1 framer G704 mode
CRC4 [ON/OFF] [N]                  Set Nth E1 framer CRC4 mode
AISDET [ON/OFF] [N]                Set Nth E1 framer AIS detection mode
AISGEN [ON/OFF] [N]                Set Nth E1 framer AIS generation mode
DSLTS [list] [N]                   Select Nth E1 channel timeslots, transmitted via DSL
WANTS [list] [N]                   Select Nth E1 channel timeslots for WAN payload
PASSWORD [USER/ADMIN]              Set user/administrator password
ID string                          Set device ID
DEFAULT [0..3]                     Set default configuration
DEFAULT EVERYTHING                 Set everything to default configuration
SERNUM                             Show serial number
APPLY [ALL/GROUP]                  Apply changes to running configuration
CONNECT [N:[1:13,R]]               Establish connection to remote unit
NET                                 Network configuration menu
M                                  Return to Main Menu
H                                  Show available commands
-----

```

CO_CM>

4.6.4.2 <AUTO [ON/OFF]> command

The <AUTO ON> command sets the CA mode for the device, i.e., all channels are in the Slave mode, automatic configuration.

In this case, all DSL interfaces pass to the Slave mode. The majority of configurations are received from the line. The MULTIPAIR mode remains unchanged.

The <AUTO OFF> command sets the manual configuration mode for the device. If this command is sent from a mode, which differs from the CA mode, it has no effect. If the command is sent from the CA mode, the current configurations of the line are written in the configuration.

4.6.4.3 <CONFIG> command

The <CONFIG> command displays the configuration of the device.

For devices in the CO, CP, CX modes:

CX_09_CM>CONFIG

Running Line Configuration

xDSL	DSL1	DSL2	DSL3	DSL4
Mode	: Master (HTU-C)	Master (HTU-C)	Slave (HTU-R)	Master (HTU-C)
Line coding	: PAM32	PAM32	PAM16	PAM32
Baserate	: 64	89	32	Auto
Annex	: A	A	A	AB
Payload	: E1-1,2,WAN	WAN	E1-3,WAN	E1-4,WAN
Clock source	: E1-2,E1-1	Int	E1-3	Ext,E1-4
Reserve	: ---	---	---	---
E1	E1-1	E1-2	E1-3	E1-4
G.704 framing	: ON	ON	ON	ON
CRC4	: ON	ON	ON	ON
AIS Detection	: ON	ON	ON	ON
AIS Generation	: OFF	ON	ON	ON
TS into DSL	: 0-16	1-31	0-31	0-31
TS for WAN	: 17-31	NONE	NONE	NONE

CX_09_CM>

For devices in the CA mode:

CA_09_CM>CONFIG

Running Line Configuration

xDSL AUTO	DSL1	DSL2	DSL3	DSL4
Mode	: -----	All slave,	AUTO ON	-----
Line coding	: PAM32	PAM32	PAM32	PAM32
Baserate	: 89	89	89	89
Annex	: A	A	A	A
Payload	: E1-1,2,WAN	WAN	E1-3,WAN	E1-4,WAN
Clock source	: E1-1,2	Int	E1-3	E1-4
E1 AUTO	E1-1	E1-2	E1-3	E1-4
G.704 framing	: ON	ON	ON	ON
CRC4	: ON	ON	ON	ON
TS into DSL	: 0-31	1-31	0-31	0-29
E1 MANUAL				
AIS Detection	: ON	ON	ON	ON
AIS Generation	: ON	ON	ON	ON
TS for WAN	: NONE	NONE	NONE	30-31

CA_09_CM>

Definitions:

Group of xDSL parameters

Mode	Operation mode:
	Master
	Slave
	Multipair
	All slave, configured by master
	All slave, MULTIPAIR xx, configured by master

User Manual

Line coding	Type of the line encoding (PAM32, PAM16, PAM8)
Baserate	Data transmission rate over the line interface. Auto – adaptation mode
Annex	Transmission mode (ANNEX A, ANNEX B, ANNEX AB)
Payload	Data transmitted over the interface: the list of E1 streams transmitted over this interface or/and WAN
Clock source	List of priority clock sources
Reserve	The reservation group to which the DSL channel belongs.

Group of E1 parameters

G.704 framing	Framing mode
CRC4	CRC4 mode
AIS Detection	AIS detection mode
AIS Generation	AIS generation mode
TS into DSL	List of time slots of E1 transmitted/received over DSL
TS for WAN	List of time slots of E1 used for WAN data and WAN (Ethernet over E1)

Note: New configuration is displayed automatically every time changes are made to the configuration.

The main operation modes of a device are:

Independent channels (CO, CP, CX, CA)

Independent channels with reservation (CO, CP, CX)

Multipair mode (CO, CP, CX, CA)

Two-pair mode with reservation (available only in the four-channel version) (CO, CP, CX)

The CONFIG table for the mode with independent channels is presented above. The table lists all possible configurations of independent channels. Typical configurations for other modes are presented below.

Table representing the mode of “independent channels with reservation”. In this configuration, channels 1, 2, 3 are combined for reservation (CO, CP, CX).

CO_09_CM>CONFIG

Running Line Configuration

xDSL	DSL1	DSL2	DSL3	DSL4
Mode	: Master (HTU-C)	Master (HTU-C)	Master (HTU-R)	Master (HTU-C)
Line coding	: PAM32	PAM32	PAM32	PAM32
Baserate	: 89	89	89	89
Annex	: A	A	A	A
Payload	: E1-1, WAN	E1-2, WAN	E1-3, WAN	E1-4, WAN
Clock source	: E1-1	E1-2	E1-3	E1-4
Reserve	: {=====	Reserve group A	=====}	---

User Manual

E1	E1-1	E1-2	E1-3	E1-4
G.704 framing :	ON	ON	ON	ON
CRC4 :	ON	ON	ON	ON
AIS Detection :	ON	ON	ON	ON
AIS Generation:	OFF	ON	ON	ON
TS into DSL :	0-31	0-31	0-31	0-31
TS for WAN :	NONE	NONE	NONE	NONE

CO_09_CM>

Table representing the mode of “independent channels with reservation”. In this configuration, channels 1, 2 and 3, 4 are combined for reservation (CO, CP, CX).

CO_09_CM>CONFIG

Running Line Configuration

xDSL	DSL1	DSL2	DSL3	DSL4
Mode :	Master (HTU-C)	Master (HTU-C)	Master (HTU-R)	Master (HTU-C)
Line coding :	PAM32	PAM32	PAM32	PAM32
Baserate :	89	89	89	89
Annex :	A	A	A	A
Payload :	E1-1,WAN	E1-2,WAN	E1-3,WAN	E1-4,WAN
Clock source :	E1-1	E1-2	E1-3	E1-4
Reserve :	{==== Reserve group A ====}		{==== Reserve group B ====}	

E1	E1-1	E1-2	E1-3	E1-4
G.704 framing :	ON	ON	ON	ON
CRC4 :	ON	ON	ON	ON
AIS Detection :	ON	ON	ON	ON
AIS Generation:	OFF	ON	ON	ON
TS into DSL :	0-31	0-31	0-31	0-31
TS for WAN :	NONE	NONE	NONE	NONE

CO_09_CM>

Table of the multipair CO mode.

CO_09_CM>CONFIG

Running Line Configuration

xDSL	DSL1	DSL2	DSL3	DSL4
Mode :	Master (HTU-C)	Multipair	Master (HTU-R)	Multipair
Line coding :	PAM32		PAM32	
Baserate :	64		64	
Annex :	A		A	
Payload :	E1-1,2,WAN		E1-3,4,WAN	
Clock source :	E1-1,2		E1-3,4	
Reserve :	---		---	

E1	E1-1	E1-2	E1-3	E1-4
G.704 framing :	ON	ON	ON	ON
CRC4 :	ON	ON	ON	ON
AIS Detection :	ON	ON	ON	ON
AIS Generation:	OFF	ON	ON	ON
TS into DSL :	0-31	0-31	0-31	0-31
TS for WAN :	NONE	NONE	NONE	NONE

CO_09_CM>

User Manual

Table of the multipair CA mode.

```

CA_09_CM>CONFIG
-----
Running Line Configuration
-----
xDSL AUTO          DSL1          DSL2          DSL3          DSL4
Mode               : ----- All slave, AUTO ON, MULTIPAIR 2+2 -----
Line coding        : PAM32          Multipair      PAM32          Multipair
Baserate           : 64
Annex              : A
Payload            : E1-1,2,WAN      E1-3,4,WAN
Clock source       : E1-1,2          E1-3,4

E1 AUTO            E1-1          E1-2          E1-3          E1-4
G.704 framing      : ON              ON            ON            ON
CRC4               : ON              ON            ON            ON
TS into DSL        : 0-31            1-31          0-31          0-29

E1 MANUAL
AIS Detection      : ON              ON            ON            ON
AIS Generation     : ON              ON            ON            ON
TS for WAN         : NONE            NONE          NONE          30-31
-----
CA_09_CM>

```

Table of the two-pair mode with reservation.

```

CO_09_CM>CONFIG
-----
Running Line Configuration
-----
xDSL              DSL1          DSL2          DSL3          DSL4
Mode              : Master(HTU-C) Multipair      Master(HTU-R) Multipair
Line coding       : PAM32
Baserate          : 89
Annex             : A
Payload           : E1-1,2,WAN      E1-3,4,WAN
Clock source      : E1-1,2          E1-3,4
Reserve           : {===== Reserve group A =====}

E1                E1-1          E1-2          E1-3          E1-4
G.704 framing     : ON              ON            ON            ON
CRC4              : ON              ON            ON            ON
AIS Detection     : ON              ON            ON            ON
AIS Generation    : OFF            ON            ON            ON
TS into DSL       : 0-31            0-31          0-31          0-31
TS for WAN        : NONE            NONE          NONE          NONE
-----
CO_09_CM>

```

The CONFIG always displays the running line configuration. If a new configuration differs from the running one, the CONFIG command lists the running configuration and displays a warning:

```

CP_CM>CONFIG
-----
Running Line Configuration
-----
xDSL              DSL1
Mode              : Slave(HTU-R)
Line coding       : PAM32
Baserate          : 89
Annex             : A
Payload           : E1-1,WAN
Clock source      : E1-1

```

User Manual

```

E1                      E1-1
  G.704 framing : ON
  CRC4          : ON
  TS0 Generation: OFF
  AIS Detection : ON
  AIS Generation: ON
  TS into DSL   : 0-31
  TS into WAN   : NONE

```

```

-----
Warning: New line configuration differs from running line configuration!
        To view new/running line configuration, type 'CONFIG N'/'CONFIG R'.
        To apply changes in configuration, type 'APPLY LINE' or 'APPLY ALL'.
        Do not forget to 'CONFIRM' a good working configuration.

```

```
CP_CM>
```

4.6.4.4 <CONFIG R/N/S/B> command

The <CONFIG R/N/S/B> command displays either the running configuration (parameters R, N, S) or the backup configuration (parameter B).

If a command is used to change configurations of data transmission interfaces, for example BASERATE or CRC4, the new configuration is displayed if the commands are performed successfully (in this case these commands are similar to the CONFIG N command). This is determined by the fact that configurations of the LINE group, which require confirmation will not be displayed in the running configuration, but will be changed only in the new configuration. To prevent misunderstanding a warning will be displayed:

```
CP_CM>BASERATE 70
```

```

-----
New Line Configuration
-----

```

```

xDSL                      DSL1
  Mode                     : Slave(HTU-R)
  Line coding              : PAM32
  Baserate                 : 70
  Annex                   : A
  Payload                  : E1-1,WAN
  Clock source             : E1-1

E1                      E1-1          E1-2
  G.704 framing : ON              ON
  CRC4          : ON              ON
  TS0 Generation: OFF             OFF
  AIS Detection : ON              ON
  AIS Generation: ON              ON
  TS into DSL   : 0-31            0-31
  TS into WAN   : NONE            NONE

```

```

-----
Warning: New line configuration is shown, because it differs from running.
        To view new/running line configuration, type 'CONFIG N'/'CONFIG R'.
        To apply changes in configuration, type 'APPLY LINE' or 'APPLY ALL'.
        Do not forget to 'CONFIRM' a good working configuration.

```

```
CP_CM>
```

4.6.4.5 <MASTER ON/OFF/AUTO N> command

The <MASTER ON/OFF N> activates/deactivates the «MASTER» mode on the interface with the number N.

The <MASTER ON> activates the MASTER mode. The <MASTER OFF> command activates the SLAVE mode.

For single-channel modems, the command is used without the number of the xDSL channel.

Note:

1. In the data transmission systems one device should be configured as a Master device, while the other – as a Slave device.

User Manual

2. For regenerators, the parameter N is used to select the interface DSL1/DSL2 (the ON/OFF is not used).
3. The <MASTER AUTO> selects automatically the Master/Slave mode (available for regenerators only).

For example:

```
RR_CM>MASTER 1  
RR_CM>MASTER AUTO
```

```
CO_CM>MASTER ON
```

4.6.4.6 <ANNEX A/B/AB [N=1..4]> command

The <ANNEX A/B [N=1..4]> command enables the transmission standard: G.991.2 ANNEX A or G.991.2 ANNEX B, where N is the number of the interface.

The <ANNEX AB> automatically selects the transmission standard.

Note: If devices use different transmission standards, synchronization will not be established between them.

4.6.4.7 <RESERVE [list]>, <RESERVE [list] [list]> command

The <RESERVE> command allows one to combine xDSL channels into groups in order to reserve them. There can be no more than 2 groups in the system with 4 DSL channels.

The reservation groups are called A and B groups. The parameter sets the list of channel numbers separated by a comma. To simplify configuration and maintenance of devices, any groups of successive channels can be reserved. To configure the reserve group, type the following command:

```
CO_01_CM>RESERVE 1,2
```

To configure both reserve groups type the command as follows. Note then groups should not cross one another:

```
CO_01_CM>RESERVE 1,2 3,4
```

The parameter NONE deactivates reservation:

```
CO_01_CM>RESERVE NONE
```

4.6.4.8 <MULTIPAIR [MODE]> command

The <MULTIPAIR> command activates multipair mode, which allows one to merge DSL channels.

Groups of 2, 3 and 4 channels can be merged in the multipair mode. The following variants are possible:

```
CO_01_CM>MULTIPAIR 2  
CO_01_CM>MULTIPAIR 3  
CO_01_CM>MULTIPAIR 4
```

The two-pair mode can be activated simultaneously for two pairs of channels: 1-2 and 3-4. The 2+2 mode is also possible:


```
CO_01_CM>MULTIPAIR 2+2
```

4.6.4.9 <G704 ON/OFF [N]> command

The <G704 ON/OFF [N]> command activates/deactivates the ITU-T G.704 framed mode for the E1 interface, where N is the number of the E interface.

The <G704 ON> activates the ITU-T G.704 framed mode. The <G704 OFF> deactivates the ITU-T G.704 framed mode, i.e., the devices starts operating in the so-called transparent mode. For modems with one E1 channel the command is the following:

```
CO_CM>G704 ON
```

4.6.4.10 <CRC4 ON/OFF [N]> command

The <CRC4 ON/OFF [N]> command activates/deactivates the CRC4 mode for the E1 channels, where N is the number of the E1 channel.

For modems with one E1 channel the command is the following:

```
CO_CM>CRC4 ON
```

Note: The command is available in the G.704 framed mode.

4.6.4.11 <AISGEN ON/OFF [N]>, <AISDET ON/OFF [N]> commands

The <AISGEN ON [N]> command activates the AIS Generation mode for the E1 interface, where N is the number of the E1 interface. The <AISGEN OFF> command deactivates the AIS Generation mode.

The <AISDET ON [N]> command activates the AIS Detection mode for the E1 interface, where N is the number of the E1 interface. The <AISDET OFF> command deactivates the AIS Detection mode.

For modems with one E1 channel the command is the following:

```
CO_CM>AISGEN ON  
CO_CM>AISDET ON
```

4.6.4.12 <PAM 16/32 [N]> command

The <PAM 16/32> command sets the number of levels in the line code. The following options are possible – 16, 32.

For modems with one xDSL channel, the following command is used:

```
CO_01_CM>PAM 16
```

Compatibility with the ETHERLINK modem is achieved by setting BASERATE in the range from 3 to 32 and by setting the line coding equal to PAM 16.

The <BASERATE AUTO> command activates the automatic detection of PAM and Annex.

4.6.4.13 <BASERATE K/AUTO [N=1..4]> command

The <BASERATE K [N=1..4]> command sets the transmission rate K over the line xDSL interface, where N is the number of the interface.

For PAM16 the available rates (BASERATE) lie in the range from 3 to 60, and for PAM32 – from 12 to 89.

User Manual

Table 4.4 “Available rates (BASERATE) for different types of coding”.

Coding type:	Parameter:	Values:	Description:	Noise immunity for these types of coding:
PAM16	N	3..60	Transmission rate over the line interface (N*64+8) kbit/s.	Average
PAM32		12..89		Low

Warning! Use codes with the lowest number of levels (PAM16) for low rates.

On the Slave device, the <BASERATE AUTO> command adapts the rate of the Slave device to the rate of the Master device. In this case, PAM and Annex are automatically detected (opposite Annex in the <CONFIG> configuration AB appears, opposite PAM – Auto). The command does not change the Annex and PAM modes in the configuration. In the Slave mode, the <BASERATE AUTO> command automatically detects all configurations.

On the Master device, the <BASERATE AUTO> command sets the mode of adaptation to the line quality. In this case the <BASERATE AUTO> mode should be also activated on the Slave device.

For modems with one xDSL channel, the command is entered without typing the number of the xDSL channel.

4.6.4.14 <DSLTS list/NONE [N=1..4]> command

The <DSLTS list/NONE [N=1..4]> command sets transmitted/received time slots of the given E1 channel to be transmitted over the xDSL channel. Here, N is the number of the E1 interface. The List consists of numbers of separate time slots and their ranges, separated by comma.

For example: 1,5,14-19.

The empty list is set by typing NONE. Spaces in the list are not allowed. Use the “minus” sign or two dots “..” to set the range.

For modems with one xDSL channel, the command is as follows:

```
CO_CM>DSLTS 0-31
CO_CM>DSLTS 0-12,16
CO_CM>DSLTS 1..31
```

4.6.4.15 <WANTS [list] [N=1..4]> command (Ethernet via E1)

The <WANTS [list] [N=1..4]> command sets the list of time slots to be transmitted WAN data via the E1 interface. Here N is the number of the E1 interface.

The List consists of numbers of separate time slots and their ranges, separated by comma.

For example: 1,5,14-19.

The empty list is set by typing NONE. Spaces in the list are not allowed. Use the “minus” sign or two dots “..” to set the range.

For modems with one xDSL channel, the command is as follows:

```
CO_CM>WAN2TS 0-31
CO_CM>WAN2TS 12-18,19
CO_CM>WAN2TS 0-21,24
CO_CM>WAN2TS 1..21
```

Time slots used by the WAN2 data (the WAN2TS command) should differ from time slots of the E1 channel (the DSLTS command) when they are transmitted over the xDSL interface.

4.6.4.16 <PAYLOAD list/NONE [N=1..4]> command

The <PAYLOAD list/NONE [N=1..4]> command sets the list of streams transmitted over the xDSL channel. Here, N is the number of the xDSL channel.

The parameter list displays the list of E1 interfaces and WAN interfaces (Ethernet), separated by comma. The E1 interface may be denoted both by a short-form (for example, E1-1, E11), and by numbers (for example, 1). Spaces in the list are not allowed. The parameter NONE deactivates transmission of E1 and WAN over this xDSL interface.

If two streams E1 and WAN are selected to be transmitted over xDSL, the number of time slots of the xDSL channel used to transmit Ethernet data is calculated as BASERATE minus the number of time slots of the E1 stream transmitted over xDSL. For example, if BASERATE is 89, and time slots 0-31 (<DSLTS 0-31>) of the E1 interface are transmitted over xDSL, 57 time slots of the xDSL stream ($57 \times 64 = 3648$ kbit/sec) will be used to transmit WAN (Ethernet) by the <PAYLOAD E1-1, WAN> command.

For modems with one xDSL channel, the command is as follows:

```
CO_CM>PAYLOAD WAN
CO_CM>PAYLOAD WAN 1
CO_CM>PAYLOAD NONE
```

4.6.4.17 <SETCLOCK list [N=1..4]> command

The <SETCLOCK list [N=1..4]> command sets the priority list of clock sources for the xDSL channel, where N is the number of the xDSL channel. The possible clock sources are:

- External sync source. Marked as EXT, EXTERNAL (only for Sub-Rack modems);
- first E1 channel. Marked as 1, E11, E1-1, E1_1;
- second E2 channel. Marked as 1, E12, E1-2, E1_2;
- third E3 channel. Marked as 1, E13, E1-3, E1_3;
- fourth E4 channel. Marked as 1, E14, E1-4, E1_4;
- internal sync source. Marked as INT, INTERNAL.

The external clock source should be either the first one in the priority list or be not used at all. The next clock sources in the list should be E1 channels. The internal clock source should be the last one in the priority list. It is not necessary to type it in the command.

The parameter N can be absent for single-channel modems.

The list of priority clock sources should contain only those E1 channels, which are used to transmit data over the xDSL channel.

If the xDSL channel is not used to transmit E1 streams, it is possible to set any of the E1 channel as a reference clock source or to use the external (EXTERNAL) clock.

Note: If the list of E1 channels transmitted over DSL is changed by the PAYLOAD command, this command can change the list so that it corresponds to the previous two criteria.

For example:

```
CO_09_CM>SETCLOCK EXT,E1-1,E1-2
CO_CM>SETCLOCK INT
```

4.6.4.18 <PASSWORD USER/ADMIN> command

The <PASSWORD USER/ADMIN> command is used to set user and administrator passwords.

```
CO_CM>PASSWORD USER
Enter password:
Confirm password:
Ok
```

Only the administrator can perform this command. The password length is no more than 11 symbols. The password can contain Latin letters and digits.

Note: It is also possible to set an empty password (in this case, the password is not requested while opening the telnet session). This command sets the password only to access the device over the telnet protocol. When managing the devices via the RS-232 interface, the password is not requested.

4.6.4.19 <SERNUM> command

The <SERNUM> command displays the serial number of the device.

```
CO_CM>SERNUM
00Al00229
CO_CM>
```

4.6.4.20 <ID N> command

The <ID N> command is used to enter identification number of the device (N is the text containing no more than 12 symbols). This ID will be displayed atop the main menu. If the parameter is not written, the device ID will be empty.

4.6.4.21 <CONNECT N:1...13/R> command

The <CONNECT N:1..13/R> initializes management of the remote device.
See description of the <CONNECT> command in the Performance Management menu.

4.6.4.22 <NET> command

The <NET> command allows one to enter the submenu for configuration of the network subsystem and NET interfaces. Type <M> to return to the main menu.

4.6.4.23 <H> command

Type <H> to list all available commands:

```
CO_NET>H
-----
Type 'H <command>' to get additional help on <command>
NETCONFIG                Show network configuration
NETCONFIG [N/R/S/B]      Show new/running/startup/backup network configuration
INTERFACE NAME CMD PARAM Set network interfaces parameters
SPECADDR MAC VLAN QOS    Add special MAC address
SPECADDR DEL MAC         Delete special MAC address
ETHSD [10/100] [H/F]     Set Ethernet speed
ETHSD AUTO               Set Ethernet speed auto negotiation
LPPACKING WAN[1/2] SIZE  Set WAN1/WAN2 LPQ packing size
SETIP x.x.x.x            Set modem IP address
GATEWAY x.x.x.x          Set gateway IP address
NETMASK x.x.x.x          Set netmask
VID [1..8] ID            Assign VID to the VLAN specified
TRAPIP [ADD/DEL] x.x.x.x Set/delete IP address for SNMP trap messages
```

User Manual

```

COMMUNITY NAME      Set SNMP community name
NETDEFAULT           Set default network configuration
APPLY [ALL/GROUP]    Apply changes to running configuration
CONNECT [1:13,R]     Establish connection to remote unit
M                   Return to Configuration Management Menu
H                   Show available commands

```

```
-----
CO_NET>
```

4.6.4.24 <NETCONFIG [R/N/S/B]> command

Without parameters the <NETCONFIG> command displays the running configuration of the network subsystem and interfaces:

```
CO_09_NET>NETCONFIG
```

```
-----
Running Network Configuration
-----
```

VLANs & QoS

Interfaces	LAN	WAN1	WAN2	WAN3	WAN4	Int
Mode	access	trunk	trunk	trunk	trunk	access
QoS	2					7
VLAN ID	1					1
VLAN1 VID=1		+	+	+	+	
VLAN2 VID=2		+	-	-	-	
VLAN3 VID=3		+	-	-	-	
VLAN4 VID=4		+	-	-	-	
VLAN5 VID=5		+	+	+	+	
VLAN6 VID=6		+	+	+	+	
VLAN7 VID=7		+	+	+	+	
VLAN8 VID=8		+	+	+	+	
OTHER VLANs		+	-	-	-	
QoS for HPQ		3	3	3	3	
Slicing for LPQ		512	512	512	512	

Ethernet:

Port	ETH1	ETH2	ETH3	ETH4
Speed/Duplex	auto	100F	100H	10H

System:

```

MAC address      : 00:0f:d9:00:a0:89
IP address       : 10.0.8.100
Subnet mask      : 255.0.0.0
Default gateway  : 10.0.0.101

```

SNMP:

```

Send traps to IP:
Community        : COMMON
SET command      : Blocked

```

```
-----
CO_09_NET>
```

Definitions:**VLAN (VLANs & QoS) configurations**

Interfaces Port identifier of the internal Ethernet switch

Mode Type of port (trunk or access)

QoS Priority for each of access ports

VLAN ID VLAN identifier for each of access ports

VLAN1 VID=xx Configurations and identifiers (xx=1..4094) for each of 8 VLANs which are
VLAN2 VID=xx configured separately.

VLAN3 VID=xx Pluses and minuses mark transmission/locking of VLAN for each of

User Manual

VLAN4	VID=xx	interfaces.
VLAN5	VID=xx	
VLAN6	VID=xx	
VLAN7	VID=xx	
VLAN8	VID=xx	

OTHER VLANS Configurations for other VLANs, which are not configured separately.
Pluses and minuses mark transmission/locking for each of interfaces.

QoS for HPQ Minimum priority of a packet to be transmitted via the high priority queue.

Slicing for LPQ Size of slicing for low priority packets

Spec. addresses Table of special MAC addresses

Ethernet port configurations

Port	Identifier of the Ethernet port
Speed/Duplex	Operation mode of the Ethernet interface

IP-subsystem configurations (System)

MAC address	MAC address of the device
IP address	IP address of the device
Subnet mask	Subnet mask of the device
Default gateway	Default gateway of the device

SNMP configurations

Send traps to IP	List of IP addresses over which SNMP-trap packets are sent
Community	Parameter of the SNMP community
SET command	Commands SNMP SET are Enabled or Blocked

Note: The table displayed after entering the <NETCONFIG> command is too long, therefore it is displayed in parts.

Note: Modems with two HDLC interfaces (mainly, 1- and 2-channel) have only WAN1 and WAN2. When the <NETCONFIG> command is entered, the table displaying information about them is two columns shorter.

The NETCONFIG command always displays the running configuration. If the new configuration differs from the running one, the NETCONFIG command displays the running configuration and a warning:

```
CO_09_NET>NETCONFIG
```

```
-----
Running Network Configuration
-----
```

```
VLANs & QoS
Interfaces      :   LAN      WAN1      WAN2      Int
Mode           :   access  trunk    trunk    access
```

User Manual

```

QoS          :      2          7
VLAN ID      :      1          1

. . .

MAC address   : 00:0f:d9:00:a0:89
IP address    : 10.0.8.100
Subnet mask   : 255.0.0.0
Default gateway : 10.0.0.101
SNMP:
  Send traps to IP:
  Community       : COMMON
  SET command     : Blocked
-----
CO_09_NET>
Warning: New line configuration differs from running line configuration!
        To view new/running line configuration, type 'CONFIG N'/'CONFIG R'.
        To apply changes in configuration, type 'APPLY LINE' or 'APPLY ALL'.
        Do not forget to 'CONFIRM' a good working configuration.
CO_09_CM>

```

The <NETCONFIG [R/N/S/B]> command displays one of four configurations: Running, New, Startup, or Backup, depending on the parameter.

For example, the command NETCONFIG B will display the backup configuration:

```

CO_09_NET>NETCONFIG B
-----
Running Network Configuration
-----
VLANs & QoS
  Interfaces   : LAN      WAN1      WAN2      Int
  Mode         : access  trunk    trunk    access
  QoS          :      2          7
  VLAN ID      :      1          1

. . .

System:
  MAC address   : 00:0f:d9:00:a0:89
  IP address    : 10.0.8.58
  Subnet mask   : 255.0.0.0
  Default gateway : 10.0.0.101
SNMP:
  Send traps to IP:
  Community     : COMMON
  SET command   : Blocked
-----
Warning: New network configuration differs from running network configuration!
        To view new network configuration, type 'NETCONFIG N'
        To view running network configuration, type 'NETCONFIG R'
        To apply changes in configuration, type 'APPLY NET' or 'APPLY ALL'.
        Do not forget to 'CONFIRM' a good working configuration.
CO_09_NET>

```

When a command used to change the configuration of the VLAN or network, for example, INTERFACE, VID, SETIP, NETMASK, is successful, the new configuration is applied similarly to the <NETCONFIG N> command. This is determined by the fact that configurations of the group VLAN or NET, which require confirmation, will not be displayed in the running configuration, but will be changed only in the new configuration.

To prevent misunderstanding a warning will be displayed:

```

CO_02_NET>INTERFACE WAN2 ALLOW 1,2,3
-----

```

User Manual

New Network Configuration

VLANs & QoS

```

Interfaces      :   LAN      WAN1      WAN2      Int
Mode            :   access   trunk    trunk    access
QoS             :           2           7
VLAN ID         :           1           1
VLAN1 VID=1     :           +           +
VLAN2 VID=2     :           -           +
VLAN3 VID=3     :           -           +

```

. . .

```

Subnet mask      : 255.0.0.0
Default gateway  : 10.0.0.101

```

SNMP:

```

Send traps to IP:
Community        : COMMON
SET command      : Blocked

```

Warning: New network configuration differs from running network configuration!

To view new network configuration, type 'NETCONFIG N'

To view running network configuration, type 'NETCONFIG R'

To apply changes in configuration, type 'APPLY NET' or 'APPLY ALL'.

Do not forget to 'CONFIRM' a good working configuration.

CO_09_NET>

4.6.4.25 <INTERFACE NAME COMMAND PARAM > command

The <INTERFACE NAME COMMAND PARAM> command sets the operation mode of ports of the internal Ethernet SWITCH, where NAME is the port name (LAN, WAN1, WAN2, Int), COMMAND is the action performed with the interface and PARAM is one or several parameters.

The command setting the operation modes of ports of the internal Ethernet SWITCH are as follows:

<INTERFACE NAME MODE ACCESS/TRUNK>.

The <INTERFACE NAME MODE ACCESS/TRUNK> command sets the operation mode of the Trunk or Access port.

Information about VLAN and QoS is not transmitted over the interface in the ACCESS mode. Accordingly, all packets received by the interface are considered to belong to VLAN, the number of the VLAN is related to the interface and the packets have the corresponding QoS. In the TRUNK mode, packets received by the port contain the VLAN and QoS numbers. In this case, VLAN ID and QoS, assigned to the interface are ignored. The command is available only for the LAN port.

The <INTERFACE NAME VLAN [1...8]> command sets the default VLAN number for ports in the ACCESS mode.

The <INTERFACE NAME QOS [0...7]> command sets the port QoS in the ACCESS mode.

The <INTERFACE NAME ALLOW VLAN-LIST> command sets the list of VLANs which are received by the port <INTERFACE NAME ALLOW VLAN- VLAN-LIST>. All units support 8 VLANs. The VID command is used to assign the VLAN name to its number. The List of VLANs, received by the interface is checked only in the TRUNK mode. In the ACCESS mode, only one VLAN (its default VLAN) is received by the interface although there can be added special MAC addresses for which another VLAN is assigned.

For example: "INTERFACE LAN ALLOW 1, 4, 8" means that the LAN interface receives and transmits VLANs with names VLAN1, VLAN4, VLAN8.

The <INTERFACE NAME QOSTHRESHOLD [0...7]> command sets the QoS threshold for interfaces WAN1 and WAN2 <INTERFACE NAME QOSTHRESHOLD [0...7]>.

For example: "INTERFACE WAN1 QOSTHRESHOLD 4" means that all packets, whose QoS is greater or equal to the assigned ones, fall into the high priority (HP) queue. Otherwise, they fall

User Manual

into the low priority (LP) queue. Only WAN1 and WAN2 interfaces have the priority queues. If the HP queue contains at least one packet, it is this packet that will be transmitted despite the fact that the LP queue can contain a number of packets. MULTICAST and BROADCAST packets are subject to this rule as well. $0 \leq N \leq 7$.

The parameters of network interfaces set by using this command enter the group of VLAN configuration parameters, which require confirmation. That is why, after changing these parameters the operator needs to confirm changes. To apply changes, enter the Fault and Maintenance Menu (FMM) and use the `<APPLY VLAN>` command. As a result, changes in the VLAN group will be applied. Configurations being applied, use the `<CONFIRM>` command in the Fault and Maintenance Menu (FMM). If changes are not confirmed, configurations, which operated before using the `<APPLY>` command, will be used after the unit restart. If the `<APPLY VLAN>` command was sent from the Telnet session and during the changes in configurations this session was interrupted, the system waits the restoration of communication over Telnet for 5 minutes. If communication is not established within this time, the systems returns to configurations of the VLAN group written in the startup configuration.

4.6.4.26 <SPECADDR> command

The `<SPECADDR MACADDR VLAN QoS>` creates the table of special MAC addresses for the LAN port in the Ethernet mode. This table is used to change the traffic priority or the VLAN of a device, which is connected to the LAN port in the ACCESS mode. The QoS value of the LAN port can differ from the QoS value of the default port. The `<SPECADDR MACADDR VLAN QoS>` command adds a special MAC address, while the `<SPECADDR DEL MACADDR>` command deletes a special MAC address. Here, MACADDR is the MAC address of the device, VID is the VLAN identifier, QoS is the priority number of the signal quality (lies in the range from 0 to 7, where 7 the highest priority). There can be no more than eight special MAC addresses, i.e., for packets received from the LAN interface in the ACCESS mode, the system checks if the table of special MAC addresses contains the address of the source packet. If this address is present in the table, the VID and QoS taken from the table are assigned to the packet. The default VID and QoS are assigned to other packets of the LAN port.

4.6.4.27 <VID> command

The `<VID [1...8] ID>` command sets VID for the VLAN with the number 1...8 equal to the ID parameter. ID=1...4094.

8 VLANs are supported by the device, and available VID numbers assigned to the VLAN lie in the range from 1 to 4094. VID as well as QoS are an attribute of the VLAN packet.

4.6.4.28 <ETHSD 10/100/AUTO H/F [N=1..4]> command

The `<ETHSD [10H/10F/100H/100F/AUTO] [N=1..4]>` command sets the operating mode of the Ethernet port, where N is the number of the Ethernet port, 10/100 is the rate of 10 or 100 Mbit/s, F is full duplex and H is half duplex.

The `<ETHSD AUTO>` command activates the rate and duplex auto detection.

For devices with one Ethernet interface, the command is as follows:

```
CO_09_CM>ETHSD 10H 1
CO_09_CM>ETHSD AUTO 2
```

4.6.4.29 <LPPACKING WAN1/WAN2/WAN3/WAN4 SIZE> command

The <LPPACKING WAN1/WAN2/WAN3/WAN4 SIZE> command sets the low priority packet size. The transmission of packets of the maximum size (for Ethernet) over low rate interface (WAN1 – WAN4) is time consuming. This can result in delays in the transmission of high priority packets. Therefore, the long low priority packets should be fragmented before transmitting them via WAN1 – WAN4 interfaces. The <LPPACKING WAN1/WAN2 SIZE> command sets the maximum size of packets in bytes. The SIZE parameter can take the following values: 64/96/128/256/512/1024/1536.

4.6.4.30 <SETIP X.X.X.X> command

The <SETIP A.B.C.D> command sets the IP-address of the modem. The parameter A, B, C and D can take values from 0 to 255 (note that neither address of the network nor the address of the node can be equal to 0, or to 255).

4.6.4.31 <NETMASK X.X.X.X> command

The <NETMASK A.B.C.D> command sets the subnet mask of the modem.

4.6.4.32 <GATEWAY X.X.X.X> command

The <GATEWAY X.X.X.X> sets the default IP address of the router.

4.6.4.33 <TRAPIP ADD/DEL X.X.X.X> command

The <TRAPIP ADD X.X.X.X> command adds the IP-address X.X.X.X to the SNMP-trap list.

The <TRAPIP DEL X.X.X.X> command deletes the IP-address X.X.X.X from the SNMP trap list.

The list should contain no more than two IP addresses.

4.6.4.34 <COMMUNITY> command

The <COMMUNITY> command sets the SNMP community parameter used to authenticate incoming and outgoing SNMP traps: incoming requests to write and read and outgoing answers to requests and outgoing traps.

After typing COMMUNITY, an invitation is displayed to enter the community parameters.

4.6.4.35 <SNMPSET ON/OFF> command

The <SNMPSET ON> command enables processing SNMP SET requests, which allows one to configure and manage the device, however, this command makes the device sensitive to attacks over SNMP in unprotected PC networks.

The <SNMPSET OFF> command disables processing SNMP SET requests, which protects the device from network attacks, but does not allows one to configure and manage it.

Use this command to process SNMP SET requests only in protected networks. If the network is not protected, use this command during configuration and administration only.

4.6.4.36 <NETDEFAULT> command

The <NETDEFAULT> command sets the following configuration:

```
CO_09_NET>NETCONFIG
```

```
-----  
Running Network Configuration
```

User Manual

```

-----
VLANs & QoS
  Interfaces      :   LAN      WAN1      WAN2      WAN3      WAN4      Int
  Mode           :   access  trunk   trunk   trunk   trunk   access
  QoS            :       2
  VLAN ID        :       1
  VLAN1 VID=1    :           +       +       +       +
  VLAN2 VID=2    :           +       +       +       +
  VLAN3 VID=3    :           +       +       +       +
  VLAN4 VID=4    :           +       +       +       +
  VLAN5 VID=5    :           +       +       +       +
  VLAN6 VID=6    :           +       +       +       +
  VLAN7 VID=7    :           +       +       +       +
  VLAN8 VID=8    :           +       +       +       +
  OTHER VLANs    :           +       +       +       +
  QoS for HPQ    :           3       3       3       3
  Slicing for LPQ :           512    512    512    512
Ethernet:
  Port           :   ETH1    ETH2    ETH3    ETH4
  Speed/Duplex   :   auto    auto    auto    auto
System:
  MAC address    :   <factory address>
  IP address     :   <not changed>
  Subnet mask    :   <not changed>
  Default gateway :   <not changed>
SNMP:
  Send traps to IP:
  Community      :   COMMON
  SET command    :   Blocked
-----

```

CO_09_NET>

The modem MAC address takes the factory value. The default IP address, sub-network masks and gateway are not changed.

4.6.4.37 <DEFAULT> command

For LTUs:

The <DEFAULT N> command sets the default operation mode, where N is the mode number (there are four default operation modes).

The DEFAULT 0 command sets the following mode: PAM 32, BASERATE 89, ANNEX A, transmission of all time slots of the E1 channel and Ethernet data over DSL.

The DEFAULT 1 command sets the following mode: PAM 32, BASERATE 72, ANNEX A, transmission of the E1 stream (without Ethernet) over xDSL.

The DEFAULT 2 command sets the following mode: PAM 32, BASERATE 72, ANNEX A, PAYLOAD 72.

The DEFAULT 3 command sets the following mode: PAM 16, BASERATE 32, ANNEX A, transmission of all time slots for the first E1 channel (without Ethernet).

4.6.4.38 <DEFAULT EVERYTHING> command

The <DEFAULT EVERYTHING> command sets default operation modes for line parameters (see the DEFAULT command), and for network parameters (see the <NETDEFAULT> command).

The result of this command is similar to the result of two commands:

```

DEFAULT 0
NETDEFAULT

```

4.6.4.39 <M> command

The <M> command in the NET submenu displays the Configuration Management menu.

5 SOFTWARE DOWNLOADING


The device hardware allows using new functions by updating the software. The downloading of the software can be performed as follows:

- via the RS232 port by using the “Flash Loader” program;
- via the RS232 port by using the X-modem protocol;
- via Ethernet (the X-modem protocol).


5.1 Software loading via the RS232 port with the help of the Flash Loader program

To download the software to the device, do the following:


1. Switch off the device. Check the value of the voltage in the electrical supply network ($\sim 220 V_{AC} \pm 10\%$; $38.72 V_{DC}$).
2. Connect the Monitor connector of the device with the Com port (RS232) of the PC.
3. Double-click “flashloader.exe”;
4. Select “*Set Loader Communication*” in the “*Setting*” menu; then, select the settings as those shown in the Figure below and click “OK”.




5. Select «*Select Device*» in the «*Setting*» menu, then select «*SA-PAM*» and click «*Ok*».



6. Select the «SSS» file and click Open.
7. Select «Connect COM» in the «Action» menu.

User Manual

8. Switch on the device being activated.




9. Click «Yes» in the “Flashloader” window.

10. The loading progress will be displayed in the window “Flash Loader: Send Panel”.



11. If the loading is successful, the following window will be displayed:



12. Click «Ok».

13. Select «Disconnect COM» in the «Action» menu.

14. Switch off the device being loaded and disconnect it from the PC.

15. Follow items 1, 2, 7 – 15 to load the software into other devices.


User Manual**5.2 Software loading via the COM port (the X-modem protocol)**

To download the software to the device, do the following:

1. Switch off the device. Check the value of the voltage in the electrical supply network ($\sim 220 V_{AC} \pm 10\%$; $38.72 V_{DC}$).
2. Connect the Monitor connector of the device with the Com port (RS232) of the PC.
3. Run the Hyper Terminal program (hyperterm.exe).
4. Create a new connection in the Connection Description window. Input the name of the connection in the "Name" field. Click "OK".



5. Then, the Connect To window is displayed. Select the COM port connected to the shelf in the "Connect Using" drop-down menu. Click OK.




User Manual

6. Configure the parameters of the COM port (COM properties).

- bit rate: 9600
- data bits: 8
- parity: none
- stop bits: 1
- flow control: none


Click OK.



7. Select Properties in the "File" menu of the HyperTerminal program.

User Manual


8. Select the Setting tab. Select the VT100 emulation in the Emulation drop-down menu. Click OK.



9. Select Call in the "Call" menu. (If the menu is not available, the connection is established automatically. Go to item 10.)

User Manual

10. Input %XX, where XX is the slot number in the shelf. The main menu of the device is displayed.




11. Enter the «Fault and maintenance management» menu.

12. Enter the <SOFTUPDATE> command.

```
CO_09_FMM>SOFTUPDATE
Flash manufacturer: Silicon Storage Technology(SST)
Flash device: SST39LF/VF016
Start address: 0x1000000
Flash size: 2048 KB
Now upload program via XModem or 1K XModem
C
```

After typing SOFTUPDATE, the device tries to establish connection over the X-modem protocol within 60 seconds.

13. The time counter is started. Select Send File in the “Transfer” menu.



User Manual

14. Select X-Modem in the Protocol drop-down menu of the Send File window. Browse the app.bin file in the Filename field (the name of the file depends on the software version). Click Send. The HyperTerminal starts downloading the file. After the downloading is completed, the device stores the downloaded file into the memory. After the Send button is clicked, the “Xmodem file send for...” window pops up.

The screenshot shows a window titled "Xmodem file send for". It contains the following fields and controls:

- Sending:** A text box containing the file path: `T:\PROJECTS\010_FG-MGS\71_MGS4\PROGS\Soft\3.5.0.5.8\app.bin`
- Packet:** A text box containing the value `405`.
- Error checking:** A text box containing the value `CRC`.
- Retries:** A text box containing the value `0`.
- Total retries:** A text box containing the value `0`.
- Last error:** An empty text box.
- File:** A progress bar with four vertical bars, followed by a text box showing `51K of 506K`.
- Elapsed:** A text box showing `00:00:15`.
- Remaining:** A text box showing `00:02:16`.
- Throughput:** A text box showing `3421 cps`.
- Buttons:** At the bottom right, there are two buttons: "Cancel" and "cps/bps".

The window displays the software downloading statistics (the name of the file, the number of transmitted packets, the error checking method, the last error, the downloading progress, time, etc.). To cancel downloading, click Cancel.

15. If the software is downloaded, the “Xmodem file send for...” window closes automatically.
16. After the software is downloaded, input the `<RESET>` command in the “Fault and maintenance management” menu. After it, input again `%XX`, where `XX` is the slot number in the shelf into which the device is installed. The main menu of the device is displayed.
17. Enter the “Fault and maintenance management” menu and input the `<SOFTCONFIRM>` command.
18. The software downloading is completed.

5.3 Software loading via Ethernet (X-modem and Telnet)

This method of the software downloading is similar to the software downloading via x-modem (see Section 3.2). Exception is that instead of selecting the number of the COM port, select TCP/IP Socket. Select 23 for the port number (TELNET). The advantage of this type of downloading is the high rate of downloading.

6 SERVICE INSTRUCTIONS

6.1 General requirements

- Before unpacking, check if the packing box is intact and if the equipment model is consistent with that specified in the purchase contract.
- Before starting operating the device, read carefully the present technical description and service instructions. Remember that the guarantee and the free-of-charge repair will not be granted under the following conditions:
 - a) if the device or any of its parts fails due to improper installation, testing or operation.
 - b) damages resulting from:
 - 1) misuse and improper installation, including but not limited to:
 - to use the product for its normal purpose or in accordance with the instructions on the proper use and maintenance,
 - installation and use of the product in a manner inconsistent with technical or safety standards in force in the country where it is used, as well as the connection of the device to the power supply source, other than required by the technical or safety standards,
 - 2) maintenance or repair performed by unauthorized service centers and dealers;
 - 3) operation of a malfunctioning device;
 - 4) accidents, lightning strokes, flooding, water, fire, improper ventilation, voltage drops, ingress of moisture and insects inside the equipment as well as other reasons, for example, electromagnetic and other interferences which are beyond the Supplier control and do not correspond to technical conditions;
 - 5) transportation except for the cases, when shipping is performed by an authorized dealer or a service center;
 - 7) defects of the system into which this product is incorporated.

User Manual

- The equipment should be powered from a primary DC source (38 ... 72 V) with the grounded “+”.
- Environment requirements:

Temperature: from -5 to +45 °C;

Relative air humidity: from 5% to 85% at +25 °C.

- It is strictly prohibited:
 - a) to alter, delete, remove or make illegible the serial number of the device;
 - b) to adapt, adjust and change the equipment in order to improve it or extend its applications without the prior written consent of the Supplier;
 - c) to alter or adjust the equipment without the consent of the Supplier.

6.2 Evaluation of the quality of the digital channel and operation parameters

The quality of the digital channel is evaluated by:

- The ITU-T G.826 error performance monitoring of a DSL link is performed according to ITU-T Rec. G.704. The evaluation of the G.826 error performance parameters is based on CRC (Cyclic Redundancy Check) error detection. On the xDSL side, six CRC6 check bits are generated per xDSL frame. CRC6 errors are used by the software to count the block errors of the xDSL channel and to evaluate its error performance according to ITU-T Rec. G.826. The **G826** command is used to display the G.826 statistics.

- The Noise Margin performance monitoring.

The Noise Margin (NM) provides qualitative performance information of a specific link. The **NM** command is used to activate this test. This parameter is calculated according to G.991.2 and is an efficient tool for determining the qualitative performance of an xDSL link. The recommended NM values should be no less than 8 dB. This value provides the necessary reserve of the signal/noise margin.

It is recommended to perform the ITU-T G.826 test regularly.

It is recommended to perform the Noise Margin performance monitoring during acceptance tests and in case the system operates unstably. The test is used to locate the damaged cable segment.

In addition, it is also recommended to monitor regularly the quality of data transmission over E1 interfaces. On the E1 side, four CRC4 check bits are generated per sub-multiframe (SMF) and compared with the corresponding bits of the next SMF. If they do not match, the CRC4 error counter is incremented.

The **G826** command is used to display the G.826 statistics.

The correctness of configurations of network interfaces and operability can be checked by using loopback tests (LOOP1) and G.826 statistics of E1 interfaces. If LOOP1 is activated on this network interface and the G826 statistics displays errors, a conclusion can be made that the E1 network interface of the S-Access ETHERLINK II system is configured improperly or malfunctions.

6.3 Activation and deactivation of a loopback


The **<LOOP1 ON(OFF)>** and **<LOOP2 R ON(OFF)>** commands are used to activate/deactivate loopbacks from the management PC (See Section 2.6).

The **<STARTAL>** command is used to activate the analog loopback in order to test the system units.

7 APPENDICES

7.1 Example of configuration of ETHERLINK II devices

An example of organization of a data transmission system with the help of ETHERLINK II devices is presented below:



Note: The PABX (ATS in the figure) supports the CRC4 mode, if this mode is enabled. Before setting IP addresses of the system devices, make sure that these IP addresses are not used by other devices connected to the system. (Enter the PING command to check IP addresses in all networks connected to the S-Access ETHERLINK-II equipment).

We present settings of the devices below. If all these settings are configured as shown below, the user will construct a data transmission system, which will operate normally. The idea is as follows: the default settings are deleted on all the devices, then the MASTER/SLAVE mode is enabled on the modem, the network settings are configured (IP address, default subnet mask and default gateway) and finally, these settings are applied and then are written in the EEPROM.

7.1.1 Configuration of the S-Access ETHERLINK II device at the Central Office premises.

System configuration (Configuration Management menu):

<DEFAULT EVERYTHING>

— enable default settings

<POWER ON>

— switch on remote powering (the modes are activated by jumpers on the main board)

Line interface configuration (Configuration Management menu):

<MASTER ON>

— enable the Master mode

Configuration of the internal Ethernet switch (Network Management submenu):

<SETIP 10.0.2.200>

— set the IP-address of the device (depends on the configuration of the network)

<NETMASK 255.0.0.0>

— set the subnet mask (this value is the same as in the connected

User Manual

Ethernet network)

<GATEWAY 10.0.0.101>

— set the default gateway (this value is the same as in the connected Ethernet network)

Application of all configurations (Fault And Maintenance Management menu):

<APPLY ALL>

— apply all configurations (written in the running configuration)

Confirmation of all configurations (Fault And Maintenance Management menu):

<CONFIRM>

— confirm all configurations (written in the startup configuration)

7.1.2 Configuration of the S-Access ETHERLINK II device at the Customer Premises.**System configuration (Configuration Management menu):**

<DEFAULT EVERYTHING>

— enable default settings

Line interface configuration (Configuration Management menu):

<MASTER OFF>

— enable the Slave mode

Configuration of the internal Ethernet switch (Network Management submenu):

<SETIP 10.0.2.201>

— set the IP-address of the device (depends on the configuration of the network)

<NETMASK 255.0.0.0>

— set the subnet mask (this value is the same as in the connected Ethernet network)

<GATEWAY 10.0.0.101>

— set the default gateway (this value is the same as in the connected Ethernet network)

Application of all configurations (Fault And Maintenance Management menu):

<APPLY ALL>

— apply all configurations (written in the running configuration)

Confirmation of all configurations (Fault And Maintenance Management menu):

<CONFIRM>

— confirm all configurations (written in the startup configuration)

7.1.3 Configuration of the S-Access ETHERLINK II regenerator at the Regenerator Point.**System configuration (Configuration Management menu):**

<DEFAULT EVERYTHING>

— enable default settings

Line interface configuration (Configuration Management menu):

<MASTER AUTO>

— enable automatic detection of the Master/Slave mode

<BASERATE AUTO>

— enable automatic detection of the line rate

User Manual**Configuration of the internal Ethernet switch (Network Management submenu):**

<SETIP 10.0.2.202>

- set the IP address of the device (depends on the configuration of the connected network)

<NETMASK 255.0.0.0>

- set the subnet mask (this value is the same as in the connected Ethernet network)

<GATEWAY 10.0.0.101>

- set the default gateway (this value is the same as in the connected Ethernet network)

Application of all configurations (Fault And Maintenance Management menu):

<APPLY ALL>


- apply all configurations (written in the running configuration)

Confirmation of all configurations (Fault And Maintenance Management menu):

<CONFIRM>

- confirm all configurations (written in the startup configuration)

An example of a more complex organization of a data transmission system with the help of ETHERLINK II devices is presented below:



Note: Both PABXs (ATS in the figure) support the CRC4 mode, if this mode is enabled. Before setting IP addresses of the system devices, make sure that these IP addresses are not used by other devices connected to the system. (Enter the PING command to check IP addresses in all networks connected to the S-Access ETHERLINK-II equipment).

User Manual**7.2 Configuration of the S-Access ETHERLINK II device at the Central Office premises.****System configuration (Configuration Management menu):**

- <DEFAULT EVERYTHING> — enable default settings
- <POWER ON> — switch on remote powering (the modes are activated by jumpers on the main board)

Line interface configuration (Configuration Management menu):

- <MASTER ON> — enable the Master mode

Configuration of the internal Ethernet switch (Network Management submenu):

- <SETIP 10.0.2.200> — set the IP-address of the device (depends on the configuration of the connected network)
- <NETMASK 255.0.0.0> — set the subnet mask (this value is the same as in the connected Ethernet network)
- <GATEWAY 10.0.0.101> — set the default gateway (this value is the same as in the connected Ethernet network)
- <SPECADRR 00:09:26:01:8A:03 2 2> — VoIP has priority 2 in VLAN 2
- <SPECADRR 00:09:26:01:8A:04 2 2> — VoIP has priority 2 in VLAN 2
- <SPECADRR 00:09:26:01:8A:05 3 2> — management PC has priority 2 in VLAN 3
- <SPECADRR 00:09:26:01:8A:06 3 2> — management PC has priority 2 in VLAN 3
- <INTERFACE LAN QOS 1> — packet from the LAN port have priority 1
- <INTERFACE WAN1 QOSTHRESHOLD 2> — VLAN packets with QoS 2 or above have the highest priority
- <INTERFACE INT VLAN 3> — packets of the internal management port belong to VLAN 3
- <INTERFACE INT QOS 2> — packets from the LAN port have priority 0
- <INTERFACE WAN1 ALLOW 1,2,3> — transmit packets of VLAN 1,2,3 over the WAN1 port

Application of all configurations (Fault And Maintenance Management menu):

- <APPLY ALL> — apply all configurations (written in the running configuration)

Confirmation of all configurations (Fault And Maintenance Management menu):

- <CONFIRM> — confirm all configurations (written in the startup configuration)

Configuration of the S-Access ETHERLINK II device at the Customer Premises.**System configuration (Configuration Management menu):**

- <DEFAULT EVERYTHING> — enable default settings

Line interface configuration (Configuration Management menu):

- <MASTER OFF> — enable the Slave mode

User Manual**Configuration of the internal Ethernet switch (Network Management submenu):**

- <SETIP 10.0.2.201> — set the IP address of the device (depends on the configuration of the connected network)
- <NETMASK 255.0.0.0> — set the subnet mask (this value is the same as in the connected Ethernet network)
- <GATEWAY 10.0.0.101> — set the default gateway (this value is the same as in the connected Ethernet network)
- <SPECADRR 00:09:26:01:8A:03 2 2> — VoIP has priority 2 in VLAN 2
- <SPECADRR 00:09:26:01:8A:04 2 2> — VoIP has priority 2 in VLAN 2
- <SPECADRR 00:09:26:01:8A:05 3 2> — management PC has priority 2 in VLAN 3
- <SPECADRR 00:09:26:01:8A:06 3 2> — management PC has priority 2 in VLAN 3
- <INTERFACE LAN QOS 1> — packet from the LAN port have priority 1
- <INTERFACE WAN1 QOSTHRESHOLD 2> — VLAN packets with QoS 2 or above have the highest priority
- <INTERFACE INT VLAN 3> — packets of the internal management port belong to VLAN 3
- <INTERFACE INT QOS 2> — packets from the LAN port have priority 0
- <INTERFACE WAN1 ALLOW 1,2,3> — transmit packets of VLAN 1,2,3 over the WAN1 port

Application of all configurations (Fault And Maintenance Management menu):

- <APPLY ALL> — apply all configurations (written in the running configuration)

Confirmation of all configurations (Fault And Maintenance Management menu):

- <CONFIRM> — confirm all configurations (written in the startup configuration)

7.3 Configuration of the S-Access ETHERLINK II regenerator at the Regenerator Point.**System configuration (Configuration Management menu):**

- <DEFAULT EVERYTHING> — enable default settings

Line interface configuration (Configuration Management menu):

- <MASTER AUTO> — enable automatic detection of the Master/Slave mode
- <BASERATE AUTO> — enable automatic detection of the line rate

Configuration of the internal Ethernet switch (Network Management submenu):

- <SETIP 10.0.2.202> — set the IP address of the device (depends on the configuration of the connected network)
- <NETMASK 255.0.0.0> — set the subnet mask (this value is the same as in the connected Ethernet network)

User Manual


- <GATEWAY 10.0.0.101> – set the default gateway (this value is the same as in the connected Ethernet network)
- <SPECADRR 00:09:26:01:8A:03 2 2> – VoIP has priority 2 in VLAN 2
- <SPECADRR 00:09:26:01:8A:04 2 2> – VoIP has priority 2 in VLAN 2
- <SPECADRR 00:09:26:01:8A:05 3 2> – management PC has priority 2 in VLAN 3
- <SPECADRR 00:09:26:01:8A:06 3 2> – management PC has priority 2 in VLAN 3
- <INTERFACE LAN QOS 1> – packet from the LAN port have priority 1
- <INTERFACE WAN1 QOSTHRESHOLD 2> – VLAN packets with QoS 2 or above have the highest priority
- <INTERFACE INT VLAN 3> – packets of the internal management port belong to VLAN 3
- <INTERFACE INT QOS 2> – packets from the LAN port have priority 0
- <INTERFACE WAN1 ALLOW 1,2,3> – transmit packets of VLAN 1,2,3 over the WAN1 port
- Application of all configurations (Fault And Maintenance Management menu):**
- <APPLY ALL> – apply all configurations (written in the running configuration)
- Confirmation of all configurations (Fault And Maintenance Management menu):**
- <CONFIRM> – confirm all configurations (written in the startup configuration)

User Manual**7.4 Connectors' description****7.4.1 "Ethernet" connector**

Type – 4*RJ-45 (female), four connectors of 8 pins each.

Table 7.1 "Ethernet" connector

<i>Pin No.</i>	<i>Description (PC connector)</i>
1	Tx+ (transmit data)
2	Tx- (transmit data)
3	Rx+ (receive data)
4	NC (not used)
5	NC (not used)
6	Rx- (receive data)
7	NC (not used)
8	NC (not used)




(Front View)

7.4.2 “xDSL” connector

Type – RJ-45 (female), 8 pins.

Table. 7.2 “xDSL” connector

<i>Pin No.</i>	<i>Description (PC connector)</i>
1	NC (not used)
2	NC (not used)
3	xDSL interface B
4	xDSL interface A
5	xDSL interface A
6	xDSL interface B
7	NC (not used)
8	NC (not used)




(Front View)

7.4.3 “xDSL” connector (IP Regenerator)

Type Phoenix 8pol.

Table. 7.3 “xDSL” connector


<i>Pin No.</i>	<i>Description (PC connector)</i>
1	xDSL Channel 1, Side 1
2	xDSL Channel 1, Side 1
3	xDSL Channel 2, Side 1
4	xDSL Channel 2, Side 1
5	xDSL Channel 1, Side 2
6	xDSL Channel 1, Side 2
7	xDSL Channel 2, Side 2
8	xDSL Channel 2, Side 2



User Manual

7.4.4 “G703” connector (E1 interfaces for Sub Rack devices)

Type: Sub-D15, male



(Front View)


Table. 7.4 “G703” connector.

Pin No.	Signal	Description
1	RX1a	First or second E1 interface of the modem, 120 Ω output, wire A
2	FPE	Functional protective earth
3	TX1a	First or second E1 interface of modem 1, 120 Ω input, wire A
4	FPE	Functional protective earth
5	FPE	Functional protective earth
6	TX2a	Third or fourth E1 interface of the modem, 120 Ω output, wire A
7	FPE	Functional protective earth
8	RX2a	Third or fourth E1 interface of the modem, 120 Ω input, wire A
9	RX1b	First or second E1 interface of the modem, 120 Ω output, wire B
10	NC	Not used
11	TX1b	First or second E1 interface of the modem, 120 Ω input, wire B
12	NC	Not used
13	TX2b	Third or fourth E1 interface of modem 1, 120 Ω output, wire B
14	NC	Not used
15	RX2b	Third or fourth E1 interface of modem 1, 120 Ω input, wire B

User Manual**7.4.5 “G703” connector (E1 interface for Stand Alone and MiniRack devices)**

Table 7.5 “G703” connector.

<i>Pin No.</i>	<i>Signal</i>	<i>Description (PC connector)</i>
1	RX1a	First E1 interface of the modem, 120 Ω output, wire A
2	RX2b	Second E1 interface of modem 1, 120 Ω output, wire B
3	NC	Not used
4	TX1a	First E1 interface of the modem, 120 Ω input, wire A
5	TX1b	First E1 interface of the modem, 120 Ω input, wire B
6	NC	Not used
7	NC	Not used
8	NC	Not used




(Front View)

User Manual

7.4.6 “Monitor” connector (for MiniRack and Stand Alone devices)

Type: Sub-D9, female

Table 7.6 “Monitor” connector.




Pin No.	Signal	Description (*- for Stand Alone devices)
1	DA_COM/FG*	Urgent-alarm contact / protection ground *
2	TXD	Transmit data (to the modem)
3	RXD	Receive data (from the modem)
4	ND_COM/COM*	Non-urgent alarm contact / common contact *
5	SGND	Signal ground
6	DA_NC	Urgent alarm contact, normally closed
7	DA_NO	Urgent alarm contact, normally open
8	ND_NC	Non-urgent alarm contact, normally closed
9	ND_NO	Non-urgent alarm contact, normally open

7.4.7 “-48VDC” connector

Table 7.7 “-48VDC” connector.

Type: MiniFit, 4 pin.




Pin No.	Signal	Description
1	-PWR	Negative power supply terminal
2	NC	Not used
3	PGND	Protection ground
4	+PWR	Positive power supply terminal

7.4.8 “Monitor/TLM” connector (for regenerators IP and PL)

Table 7.8 “Monitor/TLM” connector.

<i>Pin No.</i>	<i>Signal</i>	<i>Description (PC connector)</i>
1	TLM1	Terminal for connection of the first dry loop
2	TLM2	Terminal for connection of the second dry loop
3	RXD	Receive data (from the modem)
4	SGND	Signal ground
5	SGND	Signal ground
6	TXD	Transmit data (to the modem)
7	TLM3	Terminal for connection of the third dry loop
8	SGND	Signal ground



(Front View)

User Manual

7.5 Ordering information

Table 7.9 Ordering information.

<i>Model</i>	<i>Description</i>
SA-PAM-RG2N-Eth-IP, V58	Dual repeater, IP-67 protected siluminium case, 2*1-pair/1*2-pair, 5704 kbit/s per pair, 1*10/100Base-T, 3 External Alarm Inputs, Remote power (up to 6 repeaters fed from one side).
SA-PAM-RG2N-Eth-PL, V58	Dual repeater, IP-67 protected plastic case, 2*1-pair/1*2-pair, 5704 Kbit/s per pair, 1*10/100Base-T, 3 External Alarm Inputs, Remote power (up to 6 repeaters fed from one side).
SA-PAM-RGN-Eth-IP, V56	Single 1-pair repeater, IP-67 protected siluminium case, 1 pair, 5704 Kbit/s, 1*10/100Base-T, 3 External Alarm Inputs, Remote power (up to 5 repeaters fed from one side).
SA-PAM-RGN-Eth-PL, V56	Single 1-pair repeater, IP-67 protected plastic case, 1 pair, 5704 Kbit/s, 1*10/100Base-T, 3 External Alarm Inputs, Remote power (up to 5 repeaters fed from one side).
SA-PAM-SA2N-2E1B/Eth, V51	Module S-Access, stand alone, 2*SHDSL, 1/2 pair, 5704 Kbit/s per pair, NTU, 2*Master/2*Slave, 2*E1 120 Ohm, 1*10/100Base-T, Local/Remote Power.
SA-PAM-SA2N-Eth, V53	Module S-Access, stand alone, 2*SHDSL, 1/2 pair, 5704 Kbit/s, NTU, M/S, 1*10/100Base-T, Local/Remote Power.
SA-PAM-SA4N-Eth, V54	Module S-Access, stand alone, 4*SHDSL, 1/2 pair, 5704 Kbit/s, NTU, M/S, 1*10/100Base-T, Local/Remote Power.
SA-PAM-SAN-E1B/Eth, V50	Module S-Access, stand alone, 1*SHDSL, 1 pair, 5704 Kbit/s, NTU, M/S, 1*E1 120 Ohm, 1*10/100Base-T, Local/Remote Power.
SA-PAM-SAN-Eth, V52	Module S-Access, stand alone, 1*SHDSL, 1 pair, 5704 Kbit/s, NTU, M/S, 1*10/100Base-T, Local/Remote Power.
SA-PAM-SR2L-2E1B/4Eth-RP, V63	Module S-Access, sub rack, 2*SHDSL, 1/2 pair, 5704 Kbit/s per pair, LTU, 2*Master/2*Slave, 2*E1 120 Ohm, 4*10/100Base-T, 2*WAN, Local/Remote Power.

User Manual

SA-PAM-SR2L-4E1B/4Eth-RP, V65	Module S-Access, sub rack, 2*SHDSL, 1/2 pair, 5704 Kbit/s per pair, LTU, 2*Master/2*Slave, 4*E1 120 Ohm, 4*10/100Base-T, 4*WAN, Local/Remote Power.
SA-PAM-SR2L-4Eth-RP, V64	Module S-Access, sub rack, 2*SHDSL, 1/2 pair, 5704 Kbit/s per pair, LTU, 2*Master/2*Slave, 4*10/100Base-T, 2*WAN, Local/Remote Power.
SA-PAM-SR4L-4E1B/4Eth-RP, V66	Module S-Access, sub rack, 4*SHDSL, 1/2/4 pair, 5704 Kbit/s per pair, LTU, 4*Master/4*Slave, 4*E1 120 Ohm, 4*10/100Base-T, 4*WAN, Local/Remote Power.
SA-PAM-SRL-2E1B/4Eth-RP, V63	Module S-Access, sub rack, 1*SHDSL, 1 pair, 5704 Kbit/s, LTU, M/S, 2*E1 120 Ohm, 4*10/100Base-T, 2*WAN, Local/Remote Power.
SA-PAM-SRL-4Eth-RP, V61	Module S-Access, sub rack, 1*SHDSL, 1 pair, 5704 Kbit/s, LTU, M/S, 4*10/100Base-T, 2*WAN, Local/Remote Power.
SA-PAM-SRL-E1B/4Eth-RP, V60	Module S-Access, sub rack, 1*SHDSL, 1 pair, 5704 Kbit/s, LTU, M/S, 1*E1 120 Ohm, 4*10/100Base-T, 2*WAN, Local/Remote Power.